

■ **お手入れ方法**

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。
使用後や保管時は以下の点を参考にしてください。

- 本製品のランプ本体が汚れた場合は中性洗剤や水を含ませた布で拭き取ってください。シンナーやアルコーンルは使用しないでください。変形、故障などの原因となる場合があります。

■ **保管方法**

- 雨露、粉塵、直射日光、紫外線、高温、多湿でない、風通しの良い乾燥した場所（0℃～ 40℃）で保管してください。
- 自動車内などの高温になる場所や極端に低温になる場所に保管しないでください。変形、発火、破裂、火災、故障などの原因となる場合があります。
- 使用しないときは電池を抜いて保管してください。
- 子供の手の届かないところに保管してください。

■ **廃棄方法**

- 廃棄方法はお住まいの自治体の収集方法に従ってください。

■ **アフターサービス**

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。
製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。
なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理をさせていただきます。

■ **仕様**

	明るさ	照射距離	照射時間
電球色 LED	5 ルーメン	5m	80 時間
高輝度白色 LED LOW	15 ルーメン	22m	73 時間
高輝度白色 LED HIGH	45 ルーメン	36m	27 時間

■ **明るさ** ルーメンとは光源から発せられる光の総量を表した光学単位で、方向や距離に関係なく光源の本来持っている性能を示しています。

■ **照射距離** 0.25ルクス（満月の明かりとほぼ同等の明るさ）以上で照らすことができる距離を示しています。

■ **照射時間** 白色LED/2m先の照度が0.25ルクスになるまでの時間を示しています。
電球色LED/初期照度に対し、10%の照度に減衰するまでの時間を示しています。

品番：1124657
品名：コンパクト ヘッドランプ
対応電池：単3形電池/1個（※ニッケル水素充電電池、リチウム電池も使用できます。）
重量：46g※（69g）内は電池を含む総重量です。
防水規格：IPX6（あらゆる方向からの強い噴流水による有害な影響がない）
主素材：ABS樹脂
付属品：単3形アルカリ乾電池/1個

■ **その他**

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont・bell

取扱説明書

コンパクト ヘッドランプ

Compact Head Lamp


この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ **特長**

本製品は汎用性の高い単3形電池1個で使用できる、大変コンパクトながらも明るいヘッドランプです。歩行を目的とした高輝度白色LEDと手元の作業に最適な電球色LEDを装備しています。誤作動を防ぐダブルクリック点灯を採用。

■ **各部の名称**



■ 安全上の注意 必ずお読みください

**警告**

場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本商品に落下等の強い衝撃を与えないでください。発熱・破損などのおそれがあります。
- 本商品の分解や改造は絶対に行わないでください。発熱・破損などのおそれがあります。
- 本商品を水中で使用しないでください。本商品は防滴仕様ですが防水機能はありません。本体内部に水が入るとショートや絶縁不良による発熱・感電・故障につながるおそれがあります。
- 使用後は必ず消灯してください。発熱・破損などのおそれがあります。
- 使用しないときは、電池を本体から取り外してください。液漏れ、発熱等のおそれがあります。
- 電池の液が目に入った時は擦らず、きれいな水で洗い、すぐに医師の治療を受けてください。
- 使いきった電池は本製品から取り出してください。電池からガスが出ることもあり、器具が破損する原因になることがあります。
- 濡れた手で電池交換をしないでください。発熱や発火、感電などのおそれがあります。

**注意**

人が障害を負ったり物的損害の発生が想定される内容です。

- 電池挿入口のキャップは確実に取り付けてください。取り付けが不充分だと、スイッチが入らない、あるいは本体内部に水が入りショートや絶縁不良による発熱・感電・故障につながるおそれがあります。
- 目に直接光を当てないでください。目に傷害を負うおそれがあります。
- 電池の使用表示に従ってください。
- 使用前は定期的に点検してください。
- 電池は消耗品です。万々に備えて予備電池をご準備ください。
- 乳幼児の手の届かないところで使用・保管してください。小さなパーツの誤飲や感電など、思わぬアクシデントの原因となる場合があります。



■ 使用前の点検 使用にあたっては、毎回必ず次のことを確かめてください。

- ☐仕様通り点灯するか
- ☐電池の液漏れや、本体の変形がないか


■ 使用方法

○ ヘッドバンドの取り付け

ランプ本体にヘッドバンドを取り付けてご使用ください。ランプ本体を取り付ける位置は右図を参考にしてください。
取り付け位置を誤ると、ヘッドバンドが固定できなくなります。




①ヘッドバンドの上部をヘッドバンドホルダーに差し込んでください。




②下部をヘッドバンドホルダーに差し込んでください。


○ 電池の交換方法



①電池挿入口のキャップをOPEN表示の方向に回して外します。



②電池の⊕⊖を間違えないように入れてください。




③本体の▶マークとキャップの—マークを合わせ、CLOSE表示の方向に回します。本体の—マークとキャップの—マークが合うまで確実にしめてください。


○ 点灯モードの切り替え方法

※本製品はバックパックやかばんの中で不意にスイッチが押され点灯することのない、ダブルクリック点灯式です。

- ①スイッチをダブルクリックする(1秒間に2回押す)と電球色が点灯します。
- ②スイッチを押すごとに、図のように点灯モードが切り替わります。
- ③点灯モードに関わらず3秒以上同じモードで点灯を続けると、次にボタンを押した際に消灯します。
- 緊急時は点滅させることにより、自分の位置を知ることが出来ます。



○ 照射角度の調節方法



本体を上下に動かし、LEDの照射角度を調節します。
※可動範囲以上には動かさないでください。

トラブルについて

スイッチを入れても点灯しない

電球色は点灯するが、メインライトが点灯しない

LOWは点灯するが、HIGHは点灯しない

電池の入れ方が逆になっている

電池が消耗している

電池の⊕⊖を正しく入れる

新しい電池に取り替える

Care

Improper care and storage of your boots can shorten their lifespan.
Follow the recommendations below to extend the lifespan of your boots.

To clean the headlamp use a damp cloth to remove dirt and dust, using a neutral detergent when necessary. Do not use alcohol or paint thinners as they can damage the unit.

Storage

- Store in a well ventilated, cool, dry place. Keep out of direct sunlight and ultraviolet light.
- Do not store in a car or places subject to temperature extremes.
- Remove batteries when not in use.
- Keep out of the reach of children.

Disposal

- Please follow local regulations regarding waste disposal.

Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair the product, or replace it, at our discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate.

Specifications

	Lumens	Beam Distance	Burn Time
Warm-light LED	5	5m	80 hours
White LED (low)	15	22m	73 hours
White LED (high)	45	36m	27 hours

■ **Lumens** Lumens are a unit that measures the total amount of light emitted from a light source in all directions.

■ **Beam Distance** The maximum distance at which a light source is able to emit usable light (0.25 lux*).

■ **Burn Time** White LED / Time tested to 0.25* lux at 2 meters.

Warm-light LED/ Time tested to 10% of initial lumens.

*Approximate to the light of a full moon on a clear night.

Style# : 1124657

Name : Compact Head Lamp

Batteries : 1 AA Battery (Compatible with nickel-hydrate rechargeable batteries and lithium batteries)

Weight : 46g (69g including battery)

Water-resistance : IPX6 (Water projected in powerful jets against the enclosure from any direction shall have no harmful effects.)

Material : ABS Plastic

Included items : 1 AA Alkaline Battery

Others

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

www.montbell.com

mont-bell

User's Manual

Compact Head Lamp

Compact Head Lamp


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Description

This headlamp is lightweight and extremely compact making it great for bringing with you everywhere. It has a white LED which is bright enough for walking in the dark and a warm-light LED perfect for cooking dinner or reading in your tent. To prevent accidentally turning on in your backpack, this headlamp has a double click feature requiring two clicks within one second to turn on. This headlamp uses one AA battery.

Components



Safety Warnings! Please read carefully.

WARNING! Under certain conditions, use of this product can result in injury, death, or property damage.

- Dropping or strong shocks to the unit may damage or cause overheating.
- Modifying or altering the unit may damage or cause overheating.
- Do not use underwater. Although this is IPX6 rated, it is not water proof. Water entry can cause shorts resulting in overheating, electrocution and damage.
- To prevent damage or overheating the unit, turn off after use.
- To prevent overheating and battery leakage, remove batteries when not in use.
- If eyes are accidentally exposed to battery acid, flush eyes with clean water and seek medical attention immediately.
- Drained batteries can release gases which can damage the unit. Remove drained batteries.
- Replacing batteries with wet hands can cause shorts resulting in overheating, fire and electrocution.

CAUTION! Under certain conditions, use of this product can result in injury or property damage.


- When replacing batteries, make sure to securely close the battery cap. Headlamp may not turn on and water entry can cause shorts resulting in overheating, electrocution and damage.
- Never shine light directly at a person's eyes.
- Follow instructions when replacing batteries.
- Prior to use, inspect the unit.
- Batteries drain over time. Always bring extra batteries in case of emergencies.
- Keep out of the reach of children.

Prior to use, inspect this product for:


- ☐ Headlamp is in good working order.
- ☐ Battery leakage, damage or irregularities.

Directions


Attaching the headlamp



2




1 Insert top of the headband into the headband holder.




2 Insert bottom of the headband into the headband holder.


Replacing batteries



1 Turn the battery cap in the open direction.



2 Insert batteries in the correct direction.




3 Line up the triangle mark on the headlamp and the minus mark on the battery cap. Turn the battery cap until secure, making sure to line up the minus marks on the headlamp and battery cap.


Switching lighting modes

※ To prevent accidentally turning on, this headlamp has a double click feature.

- 1 Click the power button twice within one second to turn on the headlamp. (⇒⇒)
 - 2 After turning on, clicking the power button once will change lighting modes. (⇒→)
 - 3 After three seconds in any lighting mode, clicking the power button once will turn the lamp off. (⇒→→)
- In emergency situations, use strobe mode to alert others of your location.



Angle Adjustment



Adjust angle of light by moving the headlamp up or down.

* Be careful not to adjust the headlamp too far in either direction.

Troubleshooting

Won't switch on.

Warm-light LED will turn on but not the White LED low mode.

White LED low mode will turn on but not high mode.

Check to see if battery has been inserted correctly.

Reinsert the battery

Batteries may be low.

Replace batteries

3