

mont·bell

共通取扱説明書

アルパインカーボンポール シリーズ

Alpine Carbon Pole Series


この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品は、I型グリップを採用した、登山で活躍するポールです。高い剛性と軽さを両立し、腕の動きに合わせた、より軽快で安定した歩行を実現します。シャフトのつなぎ目を角型のデザインにすることで、握りやすく弱い力でも長さ調節ができます。1本から歩行の補助として使用できますが、両手で2本を使用することで、推進力やバランス感覚をよりサポートします。

■ 各部の名称



■ 安全上の注意 必ずお読みください

警告 場合により人が死亡または重傷を負う可能性が想定される内容です。軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品は登山用です。これ以外の目的では使用しないでください。
- 登山用ピッケルではありません。グリセードやクライミングの支点として、絶対に使用しないでください。また、両端を強い力で引っ張るとグリップやシャフトが抜けてしまう可能性があります。人や荷物の引き上げに使用しないでください。
- 岩場など手を使って確保が必要な場所では、バックパックに収納するなどして使用しないでください。
- 落雷の恐れがあるときは使用しないでください。
- 使用時にシャフトの固定が不十分だと転倒などの原因となり危険です。使用前には必ず固定状態を確認してください。行動中にも緩みがないかを確認してください。
- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に保護能力が発揮できない恐れがあります。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。

注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- 周囲の人や物に危害を加える恐れがありますので、使用中は振り回さないでください。
- “STOP”表示を超えて使用しないでください。使用中に破損する恐れがあります。

- 横からの強い荷重をかけないでください。構造上、横方向からの荷重には縦方向ほどの強度はありません。
- シャフト及びストッパー部に潤滑油等を使用しないでください。確実な固定が得られず、転倒などの原因となり危険です。
- 使用しないときは、石突きに必ず付属のポイントプロテクターを装着してください。
- 収納時はシャフトが脱落することがありますのでバックパックや収納ケース等に収納してください。
- 長さ調節の際に十分に固定されているか、確実に固定されているか時々確認してください。
- ポールに全体重をかけないでください。ケガやポールが破損する恐れがあります。
- お子さまや、ご年配の方が使用する際は、周囲の人がシャフトが固定されていることを確認してください。
- 使用前および使用中も各部に異常がないか点検してください。
- 先端のポイントプロテクターがすり減った場合は速やかに専用のポイントプロテクターに交換してください。
- 高温になる場所に放置しないでください。グリップが変形したり、やけどをする恐れがあります。
- 極度の低温下ではシャフトが凍ったり、各部の機能が低下することがあります。
- グリップは素材の特性上、保水して凍ったり、雪が付着することがあります。凍る可能性のある状況での使用はお避けください。
- ツイストロックを強く締めすぎると、ストッパー内部を傷めたり、固定したまま緩められなくなる恐れがあります。


■ 使用前の点検 使用にあたっては、毎回必ず次のことを確かめてください。

- ひびや変形が見られないか
- シャフトの固定は確実にできるか

■ 使用方法

コースや地形に応じてポールの長さ、ストラップの長さを適切に調節してください。

○ 長さの調節の目安 (使用する状況に応じて長さを調節してください。)



○ 長さの調節方法

- 上下のシャフトキャップと石突き部分を持ち、下段シャフトを矢印の方向に回して固定を緩めます。下段シャフトを“STOP”表示まで伸ばしてください。
- 上段シャフトと下段シャフトを持ち、下段シャフトを矢印の方向に回して固定します。
- 中段シャフトを同じ要領で伸ばします。中段シャフトの数字を目安にポールの長さを調節し、矢印の方向に回して固定してください。


注意 シャフトを固定する際は、シャフトキャップは持たずに固定してください。必要以上に強く締めすぎると破損の恐れがあります。

注意 ポールの調節幅は“STOP”表示が隠れる位置で調節してください。表示以上に伸ばして使用すると過度な負荷がかかり、破損の原因となります。

注意 シャフトを時計回りに回して締めると、回転が重く感じるところがあります(最も緩めた状態から3回転ほど)。そこから1/2回転ほど締めたところが、適切な締め具合の目安です。
※必要以上に強く締めすぎるとシャフト内部を傷めたり、固定したまま緩められない恐れがあります。


○ 収納方法

2カ所の固定を緩めて中段シャフトと下段シャフトを収納します。収納後は矢印の方向に回して確実に固定してください。緩めたままだとシャフトが脱落する恐れがあります。




○ グリップの握り方

- ① 下方からストラップを手に通します。 ② ストラップとグリップを図のように握ります。




○ ストラップの調節方法

短くするとき



ストラップの先端を持ち、斜め下方へ引きます。

長くするとき




ストラップの輪の上側を持ち、横方向へ引きます。
※下方へは引っ張っても動きません。

○ バスケットの着脱方法

岩の割れ目などにポールが挟まる危険を防ぐ樹脂製バスケットです。安全確保のため、バスケットは必ず装着して使用してください。また、深雪ではスノーバスケット(別売)を使用してください。


■ 取り付け方

バスケットを矢印の方向に回しながら、空回りするまで差し込みます。



■ 取り外し方

バスケットを下方方向に引きながら矢印の方向に回し、引き抜きます。




○ ポイントプロテクター

独自構造の脱着しにくいラバー製キャップです。移動時や植生にダメージを与える可能性のある登山道や木道では必ず装着して使用してください。また、雪上では取り外して使用してください。

※ポイントプロテクターは消耗品です。傷んだ際は交換してください。

■ 取り付け方


カチッと音がするまで、ポールの石突きにしっかり差し込んでください。奥まで入れないと脱落する恐れがあります。



■ お手入れ方法

間違っただけのお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- ご使用後は上段、中段、下段のシャフトを全て外して汚れをよく落とし、完全に乾燥させて保管してください。
- ストッパー部に潤滑油等を使用しないでください。確実な固定が得られず、転倒などの原因となり危険です。



■ 保管方法

- 本製品を長期間使用せずに保管する場合は、直射日光の当たらない風通しの良い場所に保管してください。
- 火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。

■ 廃棄方法

- 廃棄方法は住まいの自治体の収集方法に従ってください。

■ アフターサービス

お問い合わせいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お問い合わせいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違っただけのお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ オプション(別売)

本製品は下記の別売のオプションを利用することができます。

- **トレッキングバスケット**
破損、紛失時の交換用のバスケットです。
- **ポールクリップ**
2本のポールをまとめることができます。
- **ポイントプロテクター**
消耗した際の交換用のキャップです。
- **ポイントプロテクター ウォーキング**
推進力を高める形状をしたラバー製キャップです。
- **スノーバスケット**
積雪期の歩行に適した交換用バスケットです。
- **アルパインカーボンポール用 ストッパー(交換用)**
シャフトの固定力が無くなった際に交換するパーツです。

■ 仕様・サイズ

品番: 1140189	品名: アルパイン カーボンポール	使用長: 105~130cm
品番: 1140250	品名: アルパイン カーボンポール S	使用長: 90~115cm
品番: 1140191	品名: アルパイン カーボンポールアンチショック	使用長: 105~130cm
品番: 1140251	品名: アルパイン カーボンポールアンチショック S	使用長: 90~115cm
素材: (シャフト)カーボン繊維強化プラスチック、アルミニウム合金 (グリップ)EVA (ストラップ)ナイロン		

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont-bell

User's Manual

Alpine Carbon Pole Series

Alpine Carbon Pole Series


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

■ Description

An I-grip and lightweight yet highly durable construction provide stability on various terrain. Features a twist lock system which securely locks with a minimal effort. For best results, use 2 trekking poles to reduce strain on your knees when going downhill and to provide extra push when going uphill.

■ Parts



■ Safety Warnings! Please read carefully.

⚠ WARNING! Under certain conditions, use of this product can result in injury, death, or property damage.

- For hiking and trekking use only.
- Do NOT use as an alpine axe, for glissading or as an anchor for climbing. Do NOT pull strongly on both ends of the pole as the shaft or grip can come apart. Do NOT use the pole for pulling up people or luggage.
- In rocky terrain where climbing is necessary, store poles in your backpack or its stuff sack to free up your hands.
- Do NOT use if there is a chance of lightning.
- If the shaft is not properly secured, the shaft can come apart or slide closed during use and result in a falling accident. Prior to use, check to see if the shafts are properly locked in place and periodically check for loosening.
- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair function.
- Prior to use, check the product's condition and stop using immediately if you notice any damage or irregularities.
- Please follow recommended care and storage instructions. Improper care and storage can lead to a decrease in performance.

⚠ CAUTION! Under certain conditions, use of this product can result in injury or property damage.

- Do NOT swing or wave poles around. May result in injury and property damage.
- Do NOT extend pole shafts further than the "STOP" marking. This may damage the stopper during use.
- Do NOT apply a strong horizontal force to the pole. Poles are not designed to support lateral forces.

- Do NOT apply lubricants to the shaft and stopper. If the shaft is not properly locked, the shaft can come apart or slide closed during use and result in a falling accident.
- Attach protector when pole is not in use.
- When not in use, store the pole inside a stuff sack or backpack. Loose shafts can become dislodged and fall.
- During use, periodically check shaft for loosening.
- Never place your full weight onto this pole.
- If someone in your party cannot verify if the shaft is stable, such as a child, have someone in the group help verify the pole is safe to use.
- Prior to, during and after use, check the pole's condition for damage and irregularities.
- Replace the protector if it shows signs of heavy wear.
- Exposure to heat can cause the grip to deform and metal to become hot.
- Exposure to freezing temperatures can freeze the shaft and impair performance.
- During cold weather, snow can stick to the grip, which may absorb moisture and freeze. Not recommended for use in freezing temperatures.
- Do NOT tighten the Twist Lock too hard. It may damage the Stopper, impairing the functions.

■ Prior to use, inspect this product and make sure:

- There are no cracks, damage or other irregularities.
- Shafts are securely locked.

■ Directions

*Adjust pole length and strap length based on trail conditions and terrain for improved comfort while trekking.

○ Optimal Pole Length



Level Terrain
Choose a length so the angle between your arm and the trekking pole is 90 degrees.



Ascending
Shorten the pole to make it easier to place the pole in front of you.



Descending
Lengthen the pole to make it easier to place the pole in front of you.



Traverse
Hold the side closest to the mountain at a lower position and the side closest to the valley at a higher position.

○ Adjusting Pole Length

1 While holding the upper and lower shaft caps with one hand, and the pole tip with the other, turn the lower shaft in the direction of the arrow to loosen. Extend the lower shaft to the "STOP" mark.

2 While holding the upper shaft, turn the middle shaft in the direction of the arrow to lock it.

3 Extend the middle shaft the same way. Adjust the length of the pole and turn the middle shaft in the direction of the arrow to lock it. Use the numbers on the middle shaft as a guide.


⚠ CAUTION! Do NOT lock the shaft while holding the shaft cap. May result in tightening the shaft too much.

⚠ Optimal Tightness to Lock
Make an extra 1/2 turn after the rotation becomes stiffer (it gets stiffer after approx 3 full turns from a loose state.)
*Do NOT tighten the Twist Lock too hard. It may damage the stopper, impairing the functions.

⚠ CAUTION! Do NOT extend the shaft past the "STOP" marking. Extending the shaft past this marking result in damage.

○ Storing



Loosen and slide close both the lower and middle shafts. Turn clockwise to lock in place. Loose shafts can become dislodged and fall.



○ Holding the Grip


① Put your hand through the bottom of the strap.

② Hold the strap and the grip as in the illustration below.



○ Adjusting Strap Length

To shorten



Pull the strap end downward.

To lengthen




Pull the higher side of the strap loop to the side.

○ Attaching the basket

*The plastic trekking basket prevents the pole from getting caught in places like cracks in the rock. For safety reasons, always attach the basket before use. In deep snow, use the Snow Basket (sold separately).


■ Attachment

Twist the basket in the direction of the arrow until it secures into place.



■ Removal

While pulling downward, twist the basket in the direction of the arrow.




○ Point protector

The point protector is Montbell's original design and features a piece of rubber that helps prevent the protector from coming off. We recommend using the point protector when the poles are not in use or when there could be plants easily damaged on a trail. Remove before using on snow.

*Point protectors will wear out and eventually need to be replaced.

■ Attachment


Twist the point protector onto the pole's tip until it clicks into place. If not properly attached, point protector may become dislodged and fall off.



■ Care

○ After use, disassemble the shaft, wipe off any dirt or residue and allow to dry completely before storing.

○ Do NOT apply lubricants to the stoppers. If the shaft is not properly locked, the shaft can come apart or slide closed during use and result in a falling accident.



3

■ Storage

- Store in a well-ventilated, cool, dry place. Keep out of direct sunlight and ultraviolet light.
- Do NOT store in a car or places subject to temperature extremes.

■ Disposal

- Please follow local regulations regarding waste disposal.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Accessories (Sold separately)

The following accessories are available for use with this product.

- **Trekking Basket**
Replacement basket.
- **Pole Clip**
Holds two I-Grip Series poles together.
- **Trekking Pole Case**
Stores two poles.
- **Stoppers for Alpine Carbon Pole**
Internal parts for when shafts no longer lock in place.
- **Point Protector Walking**
Guard with excellent gripping abilities.
- **Snow Basket**
Basket for trekking in snow.

■ Specifications

Style# : 1140189	Name : Alpine Carbon Pole	Usable length : 105~130cm
Style# : 1140250	Name : Alpine Carbon Pole S	Usable length : 90~115cm
Style# : 1140191	Name : Alpine Carbon Pole Anti Shock	Usable length : 105~130cm
Style# : 1140251	Name : Alpine Carbon Pole Anti Shock S	Usable length : 90~115cm
Material : (Shaft)Carbon fiber reinforced plastic, Aluminum alloy (Grip) EVA (Strap) Nylon		

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

<https://www.montbell.com/>

4

44-4460-2109