

## Care

Improper care and storage can shorten the lifespan of this product.  
Follow the recommendations below to extend the lifespan of your pocket.

- Avoid direct sunlight and allow to air dry in a cool, well ventilated area. If stored wet or soiled, mold can grow and the fabric can start to prematurely deteriorate.
- Use a water repellent treatment (such as Montbell's SR Spray) to restore the fabric's water repellency and stain resistance.

## Storage

- When storing for an extended period of time, store loosely in a well ventilated, cool, dry place out of direct sunlight. Tents, tarps, and shelters are not designed to be stored long term in their stuff sacks and should only be used for transport.
- To prevent deforming and damage to tents, tarps, and shelters, do not store near heat sources.

## Disposal

- Please follow local regulations regarding waste disposal.

## Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at our discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

\*Socks will wear out over time. In case of rips and tears, the pair of socks may be repaired. For more information, please contact Montbell Customer Service or the store of original purchase.

## Specifications

**Style#** : 1126192  
**Name** : Kayak Fishing Dry Pants  
**Included** : DRYTEC® 3-layer (Outer layer: 75×150-denier polyester taffeta)

All product specifications and design are subject to change without prior notice.  
Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN  
www.montbell.com

mont-bell

## 取扱説明書

# カヤックフィッシング ドライパンツ

## Kayak Fishing Dry Pants

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## 特長

カヤックフィッシングに必要な機能を搭載したドライパンツです。パドリング時の姿勢を考慮したデザインを採用し、独自開発した耐水圧 30,000 mm を誇る防水透湿性素材ドライテック®を使用しています。スーパードライトップ（別売）と連結することで、接続部分からの水の侵入を極めて高いレベルで防ぎます。足の先まで覆える一体型のソックスを装備しています。

※本製品は高い防水性を持ちますが、完全防水ではありません。

## 各部の名称



## ■ 安全上の注意 必ずお読みください



**警告** 場合により人が死亡または重傷を負う可能性が想定される内容です。  
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品はフィッシングでの使用を目的として開発された製品です。それ以外の目的では絶対に使用しないでください。
- 本製品に空気が多く入ったまま水中で転倒すると脚部が浮き、上体が沈んで息ができなくなる恐れがあります。着用の際は、以下の手順で必ず“空気抜き”をおこなってください。
- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に機能が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。本来の性能を発揮できない恐れがあります。



**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

- 本体とソックスのつなぎ目に極端な負荷が掛からないように注意してください。通常の使用については十分な接着強度を持っていますが、接着部に対し部分的に強く引っ張られた際は剥離を招く恐れがあります。
- 必ず靴を着用してください。靴を着用しないとソックスを傷める恐れがあります。
- 靴を着用する前にソックス内と靴の中の異物（小石、草木など）をきれいに取り除いてください。
- 深場への立ち込みや無理な渡渉はしないでください。
- 鋭利なものには近づけないでください。ピンホールが発生し、水漏れの原因となる恐れがあります。

## ■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。  
異常が見られた場合は使用しないでください。

- 本体・ソックスにピンホール等の破れがないか

## ■ 使用方法


### ○ 空気抜きの方法

本製品に空気が多く入ったまま水中で転倒すると脚部が浮き、上体が沈んで息ができなくなる恐れがあります。着用の際は、以下の手順で必ず“空気抜き”をおこなってください。

- ①調節ベルクロを緩めた状態で、膝上ぐらいの水深の場所に立ちます。その際、底が安定している流れの無い場所を選んでください。
- ②その場所でゆっくりとしゃがみ込み、本製品の内部の空気を水圧により押し出します。
- ③調節ベルクロをしっかりと締めてください。

### ○ ブーツの着用方法 ※本製品を使用する際は必ず靴を着用してください。

ブーツ等を履く際は、右図のようにグラベルガードを上げてから履いた後、ブーツにしっかりとグラベルガードを被せてください。これにより小石などの侵入を防ぎます。



2

### ○ Using with the Super Dry Top (sold separately)

#### Roll-Up Joint System™

Use the procedures below to join to the Super Dry Top (sold separately) for a highly water resistant seal along the waist. (Not completely waterproof)




Super Dry Top  
(sold separately)


\*Illustration actual product may vary




- ① Pass the waders' velcro tabs through the three loops on top's inner.




- ② Connect inners of the top and the waders.




- ③ Line up the ends of the inners.




- ④ Roll the inners up four times.




- ⑤ Roll-up complete.



- ⑥ Tightly tuck the rolled up section into the waders.



- ⑦ Firmly secure the Velcro straps on the waders.



- ⑧ Pull and secure the top's waist belt over the waders' Velcro straps.



During step ⑥, make sure to vent air from the waders. See section "Venting Air" for more information.

## ■ Repair

- For punctures and tears, use a repair kit and adhesive (sold separately, follow kit's repair instructions).
- In case of large punctures and tears, please contact Montbell Customer Service.

7

## ■ Safety Warnings!



### **Danger!**

Under certain conditions, use of this product can result in major injury or death.

- This product was designed for fishing. Do NOT use this product for any other activity for which it was not designed.
- Unvented air can become buoyant causing your head and chest to submerge, which can potentially lead to drowning. When putting on this product, immerse yourself in water and vent as much air as possible.
- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair function.
- Please follow recommended care and storage instructions. Improper care and storage can lead to decrease in performance.



### **CAUTION!**

Under certain conditions, use of this product can result in injury or property damage.

- Do NOT apply excessive force to the joints between the product and socks. Although the joints have sufficient adhesive strength when used normally, they may tear if pulled with excessive force.
- Always wear shoes to protect the socks.
- Before putting on shoes, remove small debris, such as stones or plant matter, from inside the socks and shoes.
- Do NOT walk into deep water or recklessly wade through difficult areas.
- Avoid sharp objects. Punctures may cause leaks.

## ■ Prior to use, inspect this product for:

- ☐ Punctures or other tears in the wader fabric

## ■ Directions

### ○ Venting Air


If air is not vented from this product, unvented air can potentially obstruct your ability to swim and your ability to right yourself. In serious cases, unvented air can become buoyant causing your head and chest to submerge, which can potentially lead to drowning. Before using, you must vent air out of the waders.

- ① While waist belt or Velcro straps are loose, stand in thigh deep water. Choose an area with a level bottom and calm waters with no current.
- ② Bend down allowing the water pressure to push air out of the waders.
- ③ Firmly secure the waist belt or Velcro straps.

### ○ Putting on boots

Always wear shoes when using this product

When putting on boots, fold up the gravel guard (see illustration on right Figure). Then fold down the gravel guard and secure it over the boots to prevent gravel from entering the boots.



## ○ スーパードライトップ (別売) との連結方法

### ロールアップジョイントシステム™

スーパードライトップ (別売) と連結することで、接続部分からの水の侵入を極めて高いレベルで防ぎます (完全防水ではありません)。  
連結は以下の手順でおこなうことができます。



スーパードライトップ (別売)  
※写真はイメージです。

- ① トップのインナー内側の3カ所のループに本製品の連結用ベルクロを通します。
- ② トップと本製品を連結します。
- ③ トップと本製品のインナーの先端を揃えます。
- ④ 下から上へ「4回」巻き込みます。
- ⑤ 巻き込み完了。
- ⑥ 巻き込み部分を本製品へしっかり収納します。
- ⑦ 本製品の調節ベルクロでしっかりと留めます。
- ⑧ スーパードライトップの裾を上から被せ、ウエストベルトでしっかりと留めます。



上記の手順⑥の後に本製品内部の空気をできるだけ出し切る“空気抜き”を必ずおこなってください。詳細は“空気抜きの方法”をご覧ください。

## ■ リペア方法

- 本体のピンホールやカギ裂きは、リペアシート (別売) もしくはパーマネント リペアシート (別売) を使用して補修してください。(ご使用の際は、各リペアシートに付属の説明書に従って作業を行ってください)
- リペアシートでは修理ができない大きな破れ等は、カスタマー・サービスにお問い合わせください。

## ■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。  
使用後や保管時は以下の点を参考にしてください。

- ご使用後は出来るだけ早く中性洗剤で洗い、陰干しにして乾燥させてください。  
汚れ(川の水や海水、汗など)を放置せず洗ってください。洗う際はすすぎ洗いを十分におこなってください。
- 生地(表面)の撥水性(水をはじく力)が低下したときは、SRスプレー(別売)をご使用いただくと撥水性和防汚性が高まります。

## ■ 保管方法

- 車のトランク内や直射日光のもとに長期間放置すると、変色や品質劣化を早める恐れがあります。
- フィールドでの使用後、温度が上がる車中などに濡れたまま放置しないでください。素材の劣化を招く恐れがあります。

## ■ 廃棄方法

- 廃棄方法はお住まいの自治体の収集方法に従ってください。

## ■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理できる場合はご要望により有償にて修理させていただきます。

※ソックスは消耗品です。ソックスが破れた場合は修理することができます(有償)。詳しくはカスタマーサービスにお問い合わせください。

## ■ 仕様

品番：1126192  
品名：カヤックフィッシングドライパンツ  
素材：ドライテック® 3レイヤー(表：75×170デニール ポリエステルタフタ)

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont-bell

### 取扱説明書

# Kayak Fishing Dry Pants

## Kayak Fishing Dry Pants

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

## ■ Description

Dry pants loaded with all the features necessary for kayak fishing. Made from DRYTEC®, a waterproof/breathable material that was specifically designed for water sports and boasts a water pressure resistance of 30,000mm. Use it together with the Super Dry Top (sold separately) to form an extremely waterproof dry suit. Features built-in socks for full leg coverage.

\*Though this product has excellent water resistance, it is not completely waterproof.

## ■ Components

