

# mont·bell

## 取扱説明書

# ロガー フレームパック

### Logger Frame Pack

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長

本製品は、快適な背負い心地と、日々の作業に耐える耐久性を備えた林業用の背負子です。登山用バックパックで培った背面システムを使用し、快適で疲れにくい背負い心地を実現しました。不定形の荷物をくりつけるのに便利なフックピンが付き、オプションを装着することで、さまざまな場面に対応する拡張性を備えています。

## ■ 各部の名称



## ■ 安全上の注意

必ずお読みください

**警告** 場合により人が死亡または重傷を負う可能性が想定される内容です。  
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に能力が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。

**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。
- 耐荷重を超えて使用しないでください。破損の恐れがあります。
- 本製品に荷物を載せたまま投げたり落したりしたりすると、耐荷重より軽い重量でも破損する恐れがあります。荷物を載せたまま背中からおろす際はできるだけ衝撃が起きないようにご注意ください。

## ■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。  
異常が見られた場合は使用しないでください。


- 本体に破れがないか
- バックルなどに破損がないか
- フレームにヒビや割れがないか

## ■ 使用方法

### ○ フィッティングの手順



パックがジャストフィットしている状態とは、バックパネルとショルダーハーネスが体に隙間無く接している状態のことをいいます。ご使用にあたっては、ご自身の体格に合わせて、適切なフィッティングを行ってください。

### 背面長の調節



①左図を元にご自身の背面長を計ります。本製品のショルダーハーネスは下記の背面長に対応します。

- ・S: ~51cm
- ・M: 51~55cm
- ・L: 55cm~



③ご自身のサイズに適合するショルダーハーネスのポケットに本体側のテープを左図のように通します。




④テープは根元のプレートの奥までしっかり差込み、ラダーバックルに通します。

**注意** 使用中の緩みやズレを防止するため、余ったテープは左図のように折り返して再びバックルに通しておきます。浮きや余裕がないようにテープはしっかり引き切ってください。

## 背負い方

本製品の各バックルに通したテープをあらかじめ適度に緩めておきます。また、実際の使用状態での正しいポジションを得るために、まず 10kg 程度の荷物を本製品に載せます。




バックを背負い、腹部を圧迫しないように腰骨部分でヒップベルトを締めます。  
ショルダーハーネスが体にフィットするようにショルダーストラップを引きます。  
ヒップスタビライザーを引いて底部の左右の揺れを防ぎます。  
ショルダースタビライザーを引き、上部の重心を体に引き寄せ安定させます。  
ショルダーハーネスを安定させるためにチェストサポートを留めます。

以上で、本製品の基本的なフィッティングは完了です。ただし、各テープ類の長さは身に着ける服によっても変わりますので、その都度の微調節が必要です。苦しくない範囲でしっかり締めてください。

## テープテンションについて

本製品はテープテンションを張ることで、腰にフレームが干渉しにくくなっています。ご使用を続けるうちに、テープテンションが緩むことがあるため、ご使用前に図の通りテープを引いて張り具合を調節してください。

### テープの張りを強くする方法



## お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用后や保管時は以下の点を参考にしてください。

- 汗による汚れや泥の汚れは水で軽く洗い流した後に中性洗剤を含ませたスポンジでブラッシングをし、洗剤を洗い流してから陰干してください。
- ドライクリーニングや洗濯機による洗濯はしないでください。生地を傷める恐れがあります。
- 乾燥機を使用しないでください。製品の寿命を縮める恐れがあります。
- 長期の使用により、はっ水性能(水を弾く力)が低下した場合は別売のはっ水スプレー等をご使用ください。

## 保管方法

- 高温になる場所を避け、風通しの良い場所に保管してください。
- ガンソリンやシンナーと一緒に保管しないでください。

## 廃棄方法

- 廃棄方法はお客様の自治体の収集方法に従ってください。

## アフターサービス

お問い合わせいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お問い合わせいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

## オプション(別売)

本製品は下記のオプション(別売)を利用できます。

本製品に下記の①②③のいずれかを取り付けることが可能です。また①と③、②と③を組み合わせて取り付けることもできます。

### ①ロガー フレームバック ギアラップ

道具を仕分けして運搬できる、丈夫な素材で作られたカバーです。さまざまなポケットを備え、チェーンソーをはじめお持ちの装備を収納できます。

### ②ロガーキャリア ギアコンテナ

パッキングを気にせずあらゆるものを入れて運搬できる、丈夫な素材で作られたケースです。

### ③ロガー フレームバック エクストラバッグ

道具と分けて食料等を収納するのに便利な、丈夫な素材で作られたバッグです。

## 仕様

- 品番: 1132217
- 品名: ロガー フレームバック
- 素材: (フレーム)アルミニウム合金(φ25mm)  
(表地)420デニール・バリスティック®ナイロン・リップストップ[ウレタン・コーティング]  
(背面)E.V.A.フォーム
- 付属品: 交換用エンドキャップ 1セット(2個)
- 耐荷重: 40kg



本製品に荷物を載せたまま投げたり落したりすると、耐荷重より軽い重量でも破損する恐れがあります。荷物を載せたまま背中からおろす際はできるだけ衝撃が起きないようにご注意ください。

## その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

# Logger Frame Pack

## Logger Frame Pack


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

## ■ Description

Drawing knowledge from Montbell's mountaineering backpacks, the durable Logger Frame Pack is specially designed for forestry work and utilizes a proprietary back panel system to provide excellent comfort. Compatible with optional items (sold separately) to match the type of forestry work.

## ■ Components



## ■ Safety Warnings! Please read carefully.

**⚠ WARNING!** Under certain conditions, use of this product can result in injury, death, or property damage.

- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- Please follow recommended care and storage instructions. Improper care and storage can lead to a decrease in performance.

**⚠ CAUTION!** Under certain conditions, use of this product can result in injury or property damage.

- Prior to use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.
- Do NOT exceed the load capacity. May result in damage to the product.
- Do NOT throw or drop this product while loaded. May damage the product regardless of load weight. Place it down as gently as possible after removing it from the back.

**■ Prior to use, inspect this product for:** Stop using immediately if you notice any irregularities.


- Damage to the fabric and straps
- Damage to the buckles
- Cracks or deformation on the frame

## ■ Directions

### ○ Fitting Process


The correct fit is achieved when the back panel and shoulder harness fit the body without any gaps. When using the pack, ensure that it is properly fitted according to your own physique.

### Adjusting Back Panel Length




① Change the shoulder harness position to match your torso length (shown on the left).


- S : ~51cm
- M : 51~55cm
- L : 55cm~



② Check the length of the shoulder harness that matches your torso length. If necessary, loosen the shoulder harness straps and pull them off.



③ Thread the strap through the tab on the shoulder harness that corresponds to your size.




④ Pull the strap until the shoulder harness is firmly connected to the base plate, then pass the strap through the ladder buckle.

**⚠** To prevent loosening or shifting of the strap during use, feed the excess strap back through the buckle again (as shown on the left). Make sure to pull the strap through tightly so that there are no loose points.



## Adjusting the stabilizers

Before starting, unbuckle and loosen all straps. To simulate conditions during actual use, load about 10kg of weight onto the frame pack.



Put the pack on, then fasten the hipbelt with it sitting on the hipbone.

Pull the shoulder straps so that they tighten around your shoulders and armpits.

Pull the hipbelt stabilizers to prevent the backpack from shifting left and right.


Pull the shoulder stabilizer to draw the backpack's center of gravity in closer to your body.

Fasten the sternum strap to secure the shoulder harness in place.

The fitting of the product is now complete. Depending on what you wear you may need to make minor adjustments to the straps and belts. Fasten straps so that they are secure, but do not cause discomfort.

## Using the tension strap

Using the tension strap helps prevent the frame from causing discomfort to the waist. The strap may slacken over time, so adjust the tension before each use by pulling the strap as shown below.



## Care

Improper care and storage will shorten the lifespan of this product. Please review the following instructions for care and storage.

- To clean stains and soiling, lightly rinse off and use a mild soap with a sponge to brush away any remaining residue. Rinse off and dry in the shade.
- Do NOT dry clean or wash in a washing machine. This can damage the product's fabric.
- Do NOT dry in a dryer. May shorten the product's lifespan.
- Water repellency will decrease over time. To restore water repellency, first clean any residues from the fabric surface and then apply a water repellent spray (sold separately).

## Storage

- Store in a well-ventilated, cool, dry place.
- Do NOT store together with gasoline or paint thinner.

3

## Disposal

- Please follow local regulations regarding waste disposal.

## Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

## Accessories (sold separately)

You can install one of the following optional accessories ①②③ to the product or customize with ①&③ or ②&③.

- ① **Logger Frame Pack Gear Wrap**  
This abrasion resistant gear wrap features many useful pockets for packing forestry equipment, such as a chainsaw.
- ② **Logger Carrier Gear Container**  
This abrasion resistant gear container provides excellent packing capacity.
- ③ **Logger Frame Pack Extra Bag**  
This abrasion resistant carrier bag provides additional packing space for separating used tools and food.

## Specifications

Style# : 1132217  
Name : Logger Frame Pack  
Material : (Frame) Aluminum (φ25mm)  
(Body) 420-denier urethane coated Ballistic nylon ripstop  
(Back panel) E.V.A. foam  
Includes : Replacement end caps 2x (1 set)  
Load capacity : 40kg

### ⚠ Important!

Do NOT throw or drop this product while loaded. May damage the product regardless of load weight. Place it down as gently as possible after removing it from the back.

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

<https://www.montbell.com/>

4

44-5306-2208