

## ■ お手入れ方法

間違っただお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- 汚れたときは、良く絞った柔らかい布でふいてください。硬い布でふいたり、強くこすると、表面に傷が付く恐れがあります。また、ガソリン、シンナー、ベンジン等の溶剤や漂白剤などは使用しないでください。
- ショートした時は必要に応じてシガーソケット内のヒューズ (15A 以上) を交換してください。

## ■ 保管方法

- 使用しない時はコード類を外して、ショートさせないようにして保管してください。
- 雨露、粉塵、直射日光、紫外線、高温、多湿、塩害のない、風通しの良い乾燥した場所 (0℃～40℃) で保管してください。
- 直射日光に曝される車の中などの高温となる場所に本製品を放置しないでください。変形や損傷の原因になります。
- 子どもの手の届かないところに保管してください。

## ■ 廃棄方法

- 廃棄方法はお住まいの自治体の収集方法に従ってください。

## ■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違っただお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

## ■ 仕様

品番: 1134115 品名: コンパクト 電動ポンプ

電源: AC100-240V, DC12V 消費電力: 24W

圧力: 0.48psi

主素材: ABS

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

株式会社 **モンベル** 本社 〒550-0013 大阪市西区新町2-2-2 <https://www.montbell.jp/>  
商品についてのお問い合わせはカスタマー・サービスまで Tel.06-6531-3544 フリーコール:0088-22-0031

44-5104-2301

# mont·bell

## 取扱説明書

# コンパクト 電動ポンプ

### Compact Electric Air Pump


この度はお買いあげいただき、誠にありがとうございます。この取扱説明書 (以下「本説明書」といいます) は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは (株) モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長

本製品は、空気注入式のスリーピングパッド [キャンプパッド100 (別売)、キャンプパッド100 ワイド (別売)] や浮き輪などにフィールドで簡単に空気を注入、排出することができる電動ポンプです。

## ■ 各部の名称



## ■ 安全上の注意 必ずお読みください

**⚠ 危険** 人が死亡または重傷を負う危険が差し迫って生じることが想定される内容です。

- 火気を近づけないでください。本製品の一部は可燃性です。破損や火災の恐れがあります。
- 雨や水がかかるような場所や湿気の多い場所では使用しないでください。感電や漏電、事故の恐れがあります。
- 本製品の改造や分解などは絶対にしないでください。感電や火災、事故の原因となります。また本来の性能が損なわれる恐れがあります。
- 高温下で使用しないでください。変形、発火、火災、故障の原因となる恐れがあります。

**警告** 場合により人が死亡または重傷を負う可能性が想定される内容です。  
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 異常や破損した状態で使用しないでください。感電や漏電、事故の原因となります場合があります。
- 重い物の下に置いたり、落下させて衝撃を与えないでください。発熱、発火、破損の原因となります場合があります。
- 寝袋や布団などに覆われた状態で使用しないでください。発熱や火災の恐れがあります。
- コードを踏みつけたり傷めたりしないでください。感電、発熱、火災の恐れがあります。
- 子どもが近づかない場所で使用してください。小さなパーツの誤飲や感電など、思わぬ事故の原因となる恐れがあります。
- 異臭、異音、発熱、発煙、変色、変形などの異常が見られた場合は直ちに使用を中止してください。故障、破裂、発火、火災などの原因となります場合があります。

**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。


- 本製品は10分以上連続して使用することはできません。長時間の使用は、モーターの過熱、ポンプが損傷する原因となります。
- 10分以上使用する場合は、一度使用を停止して10分以上本製品を冷ましてから使用してください。
- 本製品はスリーピングパッドや浮き輪などを膨らますために開発されたものです。本来の用途以外（タイヤの空気入れ等）に使用しないでください。
- 本製品のスリーピングパッド用ノズルは、キャンプパッド100（別売）、キャンプパッド100ワイド（別売）専用です。上記以外のスリーピングパッドや、他社製品は対応していません。
- 本製品は家庭用コンセント（AC100-240V）、車内用シガーソケット（DC12V）専用です。指定の電源以外で使用しないでください。
- 0℃～40℃の範囲内で使用してください。上記以外の範囲では使用しないでください。発熱、破裂の原因となります場合があります。
- 夏の車中など高温になる場所に本製品を置かないでください。熱による変形や破損する恐れがあります。
- 使用中に砂、小石、その他の小片などが本製品につまらないように注意してください。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。
- 使用後は必ずスイッチをOFFにしてから、アダプタを電源から抜いてください。

**■ 使用前の点検** 使用にあたっては、毎回必ず次のことを確かめてください。  
異常が見られた場合は使用しないでください。

本体、コード、ノズル類に破損はないか

## ■ 使用方法


### ○ ノズルの対応




- ① φ30mm ノズル…… スリーピングパッド用  
対応製品：キャンプパッド100（別売）  
キャンプパッド100ワイド（別売）  
※上記以外のスリーピングパッドには対応していません。
- ② φ17～24mm ノズル …… 口径の大きいバルブ用
- ③ φ6～9mm ノズル …… 口径の小さいバルブ用

### ○ 空気を入れる（抜く）時


① 使用するアダプタ（AC,DC）のプラグをポンプ本体のジャックに取り付け、電源につなぎます。



② 吹出口（吸込口）に製品に合わせたノズルを差し込みます。



- ③ 膨らます（しぼませる）製品のバルブにノズルを差し込み、スイッチをONにします。
- ④ 製品が膨らんだら（しぼんだら）、スイッチをOFFにします。




※イラストはキャンプパッド 100（別売）、キャンプパッド 100ワイド（別売）です。


※本製品でキャンプパッド100（別売）、キャンプパッド100ワイド（別売）の空気を抜く際は、パッド内部の空気を完全に抜く事はできません。手でパッド本体を巻いて、残った空気を抜いてください。  
※本製品は10分以上連続して使用することはできません。長時間の使用は、モーターの過熱、ポンプが損傷する原因となります。  
※10分以上使用する場合は、一度使用を停止して10分以上本製品を冷ましてから使用してください。

### スイッチの操作について

※始動する時は「ON」側にスライドし、ポンプを使用中に止めたい時は、スイッチを「OFF」側にスライドしてください。（アダプタを電源から抜く際は、必ずスイッチをOFFにしてからおこなってください。）




### ▲ 注意（不適切な使用方法）



ポンプを床に置くなど、吸込口や吹出口がふさがれた状態で使用しないでください。本製品が破損する恐れがあります。

※DCアダプタを車に接続して使用する際は、エンジンが始動している状態で使用してください。エンジンが始動していない状態だと、バッテリー上がりの恐れがあります。  
※バッテリーの電圧が下がると正常に動作しない場合があります。  
※高圧が必要なスタンドアップパドルボードやタイヤなどは使用できません。  
※比較的高い圧力が必要な気室の小さい製品（小さい浮き輪など）は、完全に膨らますことができない場合があります。



安全弁（逆止弁）付きバルブに空気を注入する場合は、上図のようにバルブの根元を指でつまみ、安全弁を開いた状態で給気してください。

## Care

Improper care and storage can shorten the lifespan of this product.  
To extend the lifespan of this product, please follow the recommendations below.

- Wipe the product with a soft, damp cloth to clean. Wiping with a hard cloth or rubbing forcefully may scratch the surface. Do NOT clean product with solvents such as gasoline, thinner, benzene, or bleach.
- If a short circuit occurs, the fuse (15A or more) in the aux. power outlet may need to be replaced.

## Storage

- When not using, disconnect the cords and store in a manner that prevents short circuits.
- Store in a well ventilated, cool, dry place. Keep out of direct sunlight and ultraviolet light.
- Do NOT store in places subject to temperature extremes, such as a car in direct sunlight. May cause deformation or damage.
- Keep out of the reach of children.

## Disposal

- Please follow local regulations regarding waste disposal.

## Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

## Specifications

Style#	: 1134115
Name	: Compact Electric Air Pump
Power source	: AC100-240V, DC12V
Power consumption	: 24W
Air pressure	: 0.48psi
Material	: ABS

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.  
2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN  
<https://www.montbell.com/>

44-5104-2301

# mont-bell

## User's Manual

# Compact Electric Air Pump

## Compact Electric Air Pump


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

## Description

Easily inflates and deflates objects such as the Camp Pad 100 (sold separately) and Camp Pad 100 Wide (sold separately) while camping, and inflatable pool floats while around water.

## Components



φ30mm nozzle: for sleeping pads

Compatible products:

Camp Pad 100 (sold separately)

Camp Pad 100 Wide (sold separately)

\*NOT compatible with sleeping pads other than those listed above.

φ6-9mm nozzles: For smaller diameter valves

φ17-24mm nozzles: For larger diameter valves

## Safety Warnings

Please read carefully.



### DANGER!

Under certain conditions,  
use of this product can result in major injury or death.

- Keep this product away from fire. Some parts are flammable. Exposing to fire may result in damage or fire.
- Do NOT use this product where it will be exposed to rain, water or excessive humidity. May cause electrocution, electrical leakages or accidents.
- Do NOT modify or alter this product. Improper modifications and alterations may cause electrocution, fire or accidents, and may negatively affect the performance of the product.
- Do NOT use this product in high temperatures. May cause deformation, combustion, fire or damage.



**⚠ WARNING!** Under certain conditions, use of this product can result in major injury or death of canine or human.

- Do NOT use the product if you notice any irregularities or damage. May cause electrocution, electrical leakage, or accidents.
- Do NOT drop, apply strong shocks, or place heavy items on this product. May cause overheating, combustion, or damage.
- Do NOT use the product while covered with a sleeping bag or bedding. May cause overheating or fire.
- Do NOT step on or damage the cords. May cause electrocution, heat generation, or fire.
- Keep out of the reach of children. Failure to do so may result in unexpected accidents such as ingestion of small parts or electrocution.
- If you notice heat, smoke, discoloration, deformation, unusual smells or noises, or any other irregularities, stop using immediately. May result in damage, rupture, overheating or fire.

**⚠ CAUTION!** Under certain conditions, use of this product can result in injury or property damage of canine or human.


- Do NOT use this product continuously for more than 10 minutes. Prolonged use may cause overheating of the motor and damage to the product.
- If using the product continuously (10 minutes or more), stop using after 10 minutes to allow the product to cool for at least 10 minutes.
- This product is designed to inflate objects such as sleeping pads and inflatable pool floats. Do NOT use this product for any other purposes (inflating tires, etc.).
- The nozzle for sleeping pads is ONLY compatible with Camp Pad 100 (sold separately) and Camp Pad 100 Wide (sold separately). Other Montbell models and sleeping pads from other manufacturers are NOT compatible.
- This product is ONLY for use with household power outlets (AC100-240V) and auxiliary power outlets (DC12V). Do NOT use this product with other power sources.
- Use this product ONLY in the temperature range of 0°C - 40°C. Use outside of this temperature range may cause overheating or rupturing.
- Do NOT leave this product in places where it will be exposed to high temperatures, such as inside a car in summer. May cause deformation or damage due to heat.
- Be careful not to allow sand, pebbles, or other small debris to clog the product during use.
- Prior to use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.
- Follow recommended care and storage instructions. Improper care and storage may lead to a decrease in performance.
- After using, always turn the switch OFF before disconnecting the adapter from the power supply.

**■ Prior to use, inspect this product for:** Stop using immediately if you notice any irregularities.

Damage to the body, cord, or nozzle

**■ Directions**


○ **Nozzle compatibility**




- ①  $\phi$ 30mm nozzle: for sleeping pads  
Compatible products:  
Camp Pad 100 (sold separately)  
Camp Pad 100 Wide (sold separately)  
\*NOT compatible with sleeping pads other than those listed above.
- ②  $\phi$ 17-24mm nozzles: For larger diameter valves
- ③  $\phi$ 6-9mm nozzles: For smaller diameter valves

○ **Inflating and deflating**


- ① Insert the plug on the adapter (AC or DC) you are using into the power socket on the main body, then connect the adapter to the power supply.



- ② Insert into the air output (intake) port the nozzle that is compatible with the object you will inflate (deflate).



- ③ Insert the nozzle into the valve on the object you will inflate (deflate), and slide the switch ON.
- ④ When the object is inflated (deflated), slide the switch OFF.



※\*Illustrated is Camp Pad 100 (sold separately) / Camp Pad 100 Wide (sold separately).


- ※When using this product to deflate the Camp Pad 100 (sold separately) or Camp Pad 100 Wide (sold separately), the air inside the pad will not be completely removed. Use your hands to roll up the pad and push out the remaining air.
- ※Do NOT use this product continuously for more than 10 minutes. Prolonged use may cause overheating of the motor and damage to the product.
- ※If using the product continuously (10 minutes or more), stop using after 10 minutes to allow the product to cool for at least 10 minutes.

**Operating the switch**

※Slide the switch towards the ON side to start the pump, and slide the switch towards the OFF side to stop the pump. (Always turn the switch OFF before disconnecting the adapter from the power supply.)




**⚠ Caution! (Improper use)**



Do NOT block the air output or intake port while using, such as by placing the pump on the floor. May cause damage to the product.

- ※When using the DC adapter connected to a car, use with the car engine running. If the engine is not running, the car battery may run out of power.
- ※If battery voltage drops, the product may not operate properly.
- ※This product is NOT compatible with objects that require high air pressure such as tires and inflatable SUPs.
- ※This product may not be able to fully inflate products with small air chambers that require relatively high air pressure (small inflatable pool floats, etc.).



To inflate an object with a safety valve (check valve), pinch the base of the valve with your fingers as shown in the figure, and inject air while the valve is open.