

■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。
使用後や保管時は以下の点を参考にしてください。

- 使用後は汚れ、水分をふき取り陰干しし、完全に乾かしてください。汚れたまま、あるいは濡れたまま長時間放置するとカビや腐食が発生する可能性があります、また劣化しやすくなります。
- 汚れがひどい場合は薄めた中性洗剤をつけた布を軽く絞り表面を拭いてください。

■ 保管方法

- 雨露、粉塵、直射日光、紫外線、塩害を受けず高温、多湿ではない、風通しの良い乾燥した場所で保管してください。
- 火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。

■ 廃棄方法

- 廃棄方法はお住まいの自治体の収集方法に従ってください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万が一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ オプション(別売)

本製品は下記の別売のオプションを利用することができます。


- **フィールド ハンモック**
軽量・コンパクトなハンモックです。
- **バグプルーフ ハンモックネット**
フィールド ハンモックに取り付けできる虫除けネットです。

■ 仕様・サイズ

品番：1122750 耐 荷 重：約100kg
品名：フィールド ハンモック スタンド ハンモックの対応サイズ：全長280cm～300cm程度

※図中の単位はcmです。

○寸法



収納サイズ：130×21×17 cm

○素材

- アルミニウム合金、スチール、ABS、ナイロン、ポリカーボネート

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

株式会社 **モンベル** 本 社 〒550-0013 大阪市西区新町2-2-2 モンベルホームページ <https://www.montbell.jp/>
商品についてのお問い合わせはカスタマー・サービスまで Tel. 06-6531-3544 フリーコール：0088-22-0031

mont・bell

取扱説明書

フィールド ハンモック スタンド

Field Hammock Stand



この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。本製品の誤った使用法は重大な事故につながる危険性があります。ご使用前に本説明書をよくお読みいただき、正しい使用法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品はキャンプサイトなどで簡単に設営できる、フィールドハンモック（別売）におすすめのハンモック用のスタンドです。工具不要で簡単に組み立てでき、付属の収納袋に入れて持ち運べるため携行に便利です。

■ 各部の名称



■ 安全上の注意

必ずお読みください

警告 場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品はハンモック専用のスタンドです。それ以外の目的では使用しないでください。
- 分解や改造は絶対に行わないでください。変形・破損の恐れがあります。
- ハンモック使用の際は大きくゆすらないでください。転落の恐れがあります。また、破損や変形の原因となる場合があります。
- お子さまがハンモックを使用する際は、必ず保護者の管理のもとで使用してください。転落の恐れがあります。
- 本製品をたき火などの火気の近くで、使用しないでください。変形や損傷の原因となります。
- 本製品は地盤のしっかりした平坦な場所を選んで設置してください。ハンモック使用時に転落の恐れがあります。また、破損や変形の原因となる場合があります。

- 使用前に毎回必ず点検をしてください。老朽化や損傷が認められたり、本製品の状態が疑わしい場合は直ちに使用を中止してください。本来の性能を発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管を行うと、本来の性能を発揮できない恐れがあります。

注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- 本製品の組み立てや収納の際は、指や手を挟まないようにご注意ください。
- 畳やフローリング、テント等の上で使用される場合は床面にキズが付く恐れがあります。
- 本製品を風雨や直射日光が当たる屋外で長期間設置しないでください。極度の劣化や腐食の原因となる恐れがあります。
- 本製品に強い衝撃をあたえたり、収納した状態で重いものを載せないでください。変形し組み立てができなくなることがあります。
- 耐荷重を超えて使用しないでください。破損の恐れがあります。
- お子さまに、本製品の組み立てや撤収をさせないでください。ケガの恐れがあります。
- 本製品は1人用です。複数人での使用はおやめください。ケガの恐れがあります。

■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。
異常が見られた場合は使用しないでください。


- ☐ 各部に亀裂や歪みなどがないか ☐ スタンドの固定が確実にできているか

■ 使用方法


※組み立ての際は指を挟まないよう十分に注意してください。

○ 本体の組み立て方法


- ①本製品を収納袋から取り出します。ベースフレームの脚が地面側にくるように置いてください。




- ②ベースフレームのジョイントのロックボタンとセンターフレームの穴の位置を合わせます。




- ③ベースフレームをセンターフレームに差し込みます。指を挟まないように注意してください。



- ④ベースフレームのジョイントのロックボタンとアームの穴の位置を合わせます。




- ⑤アームをベースフレームに差し込みます。指を挟まないように注意してください。




○ フィールドハンモックの取り付け方法

フィールドハンモック(別売)本体の取扱説明書を併せてご覧ください。お持ちのハンモック(全長280cm～300cm程度)にも対応しますが、形状によって使用できない場合があります。


- カラビナをアームの下ルのープに取り付けます。ハンモックを吊り下げる角度の目安は30°です。
- ※ハンモックを取り付ける際は、必ずアームのループを使用してください。



- ⚠ カラビナは外れないように、環を回し上げてロックします。




- ⚠ カラビナは縦方向に使用してください。横方向は十分な強度を備えていません。



⚠ 注意

ハンモックはたわませて設置してください。張る力が強いとアームに過度な負担がかかり、本製品が破損する恐れがあります。また、ハンモックが回転しやすくなり、転落の恐れがあります。



- ※フィールドハンモック(別売)の生地が伸び、張りが弱まった際は、上のループを使用してください。
- ※お持ちのハンモックを取り付ける際は、生地の手張りを見て、使用するループの位置を選択してください。
- ※フィールドハンモック(別売)付属のストラップは使用しないでください。ストラップは木に装着する際に使用してください。


⚠ 使用しないでください



○ 収納方法


- ①組み立て方法の逆の順序で収納してください。ロックボタンを解除する際は、指を挟まないように注意してください。

ロックボタンの解除方法



ロックボタンを指で押し込みながらアームとセンターフレームをベースフレームから引き抜きます。

- ②アーム(2本)、センターフレームを収納袋に収納し、一番上にベースフレームを重ねます。その際、脚が上を向くように置いてください。最後に動かないようテープで固定してください。



Care

Improper care and storage of your hammock stand can shorten its lifespan. Follow the recommendations below to extend the lifespan of the hammock stand.

- After use, wipe off any dirt or moisture and dry the product completely in the shade. If the product is left dirty or wet for extended periods, mold and corrosion may occur, and the product may quickly deteriorate.
- If heavily soiled, wipe the surface with a cloth dipped in diluted neutral detergent.

Storage

- Store in a well-ventilated, cool, dry place away from moisture, dust, direct sunlight, ultraviolet rays, salt, high temperatures and high humidity.
- Do NOT expose this product to temperature extremes, such as placing near a fire. Doing so may result in deformation or damage.

Disposal

- Please follow local regulations regarding waste disposal.

Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

Accessories (Sold separately)

The following accessories are available for use with this product.

● Field Hammock

A lightweight, compact hammock.

● Bugproof Hammock Net

A bugproof net attachable to a hammock.

Specifications

Style# : 1122750


Weight capacity : 100kg

Name : Field Hammock Stand

Compatible hammock length : approx. 280cm-300cm

○ Dimensions

*Units are in centimeters.



Folded Dimensions H:130 × W:21 cm × D:17 cm

○ Materials

- Aluminum alloy, Steel, ABS, Nylon, Polycarbonate

Others

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

<https://www.montbell.com/>

mont-bell

User's Manual

Field Hammock Stand

Field Hammock Stand


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product. Improper use of this product may result in serious accidents. Before using, read the user's manual that comes with the product to ensure proper usage.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Description

Compatible with the Field Hammock (sold separately), or your existing hammock depending on the size. Easily assembles at camp sites without needing tools and includes a carrying case, providing easy portability.

Components



Safety Warning!

Please read carefully.



WARNING!

Under certain conditions, use of this product can result in injury, death, or property damage.

- This product is designed for use with hammocks. Do NOT use with any other objects.
- Do NOT alter or modify this product in any way. Doing so may result in deformation or damage.
- When using the hammock, do NOT shake or swing excessively. May result in falling out of the hammock, and may cause deformation or damage to the product.
- Children should always be supervised by a guardian when using the hammock. There is a risk of falling.
- Keep this product away from flame sources, such as camp fires, to prevent damage and warping due to heat.
- Use product in a flat place with solid ground. Failing to do so may result in falling when using the hammock, and may cause deformation or damage.

- Prior to use, check this product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.
- Please follow recommended care and storage instructions. Improper care and storage can lead to a decrease in performance.

CAUTION! Under certain conditions, use of this product can result in injury or property damage.

- Be careful not to pinch fingers or hands when assembling or disassembling this product.
- Do NOT use this product on top of tatami, flooring or inside a tent. The stand can damage the floor.
- Do NOT leave this product for extended periods outdoors exposed to wind, rain, or direct sunlight. Doing so may cause extreme deterioration or corrosion.
- Do NOT apply strong shocks to the product, or place heavy objects on it while storing. May cause deformation and become impossible to assemble.
- Do NOT place weight on the product in excess of its load capacity. Doing so may result in damage to the product.
- Do NOT allow children to set up or dismantle this product.
- Designed for a single user at one time. Use by multiple users at the same time can result in damage to the hammock and injury.


■ Prior to use, inspect this product for:

☐ Cracks or deformation on each part. ☐ Secure locking of each part.

■ Directions *Be careful of pinching your fingers when setting up this product.

○ Assembling

- 1 Remove the product from the carrying case. Lay down the product with the legs of the base frame flat on the ground.
- 2 Align the lock button on the base frame's joint with the lock hole on the center frame.
- 3 Secure the base frame to the center frame. Be careful not to pinch your fingers.



- 4 Align the lock button on the base frame's joint with the lock hole on the arm.
- 5 Secure the arm to the base frame. Be careful not to pinch your fingers.





2

○ Connecting the Field Hammock

Also refer to the user's manual for the Field Hammock (sold separately). Can be used with your existing hammock depending on the shape and if between 280cm-300cm in length.


- Secure the carabiners to the arm loops. Aim for about a 30 degree angle when the hammock hangs.

*When attaching the hammock, always use the arm loops.



CAUTION

Set up the hammock letting it hang at about a 30° angle. If the tension is too tight, the arm will be overstrained and the product may become damaged. Hammock may easily rotate, which may cause the user to fall.



※If the fabric of the Field Hammock (sold separately) stretches and develops some slack, secure using the upper loop.

※When attaching a hammock that is not the Field Hammock, choose the upper or lower loop depending on the tension of the fabric.

※Do NOT use the straps that come with the Field Hammock (sold separately) with the Field Hammock Stand. Only use the straps when attaching the hammock to a tree.


Do NOT use.



○ Disassembling


- 1 Disassemble in the reverse order of the assembly instructions. When releasing the lock button, be careful not to pinch your fingers.

Releasing the lock button



While pressing down the lock button, pull the arm and center frame out of the base frame.

- 2 Store the center frame and 2 arms in the carrying case, and place the base frame on top with the legs facing up. Secure with the straps to prevent it from moving.



3