

mont·bell

共通取扱説明書

フォールディング フィールドチェア シリーズ

Folding Field Chair Series


この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品は高い安定性を持つ折り畳み式チェアです。背もたれとひじかけ、座面はパッド入りで、長時間座っていても疲れにくく、ゆったりとした座り心地です。ハンドル付きで、折り畳めば簡単に持ち運ぶことができます。

■ 各部の名称

※写真はフォールディング フィールドチェアです。



■ 安全上の注意

必ずお読みください



警告

場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 転倒の恐れがあるので、浅く掛けたり、ひじかけから身を乗り出すなど、無理な姿勢で使用しないでください。また、座る目的以外で使用しないでください。
- 激しく衝撃のかかるような座り方や、ゆるような座り方はしないでください。破損や変形の原因となることがあります。
- 本製品の脚に均等に荷重がかかるように座ってください。後ろに荷重をかけて前側の脚が浮いた状態になると、局部に荷重がかかると破損の恐れがあります。
- お子さまを座らせるときは、必ず保護者の管理のもとで使用してください。転倒の恐れがあります。
- 本製品は地盤のしっかりした平坦な場所を選んで設置してください。転倒の恐れがあります。
- 本製品をたき火などの火気の近くで、使用しないでください。変形や損傷の原因となります。



注意

人が傷害を負ったり物的損害の発生が想定される内容です。

- 使用前に毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合には直ちに本製品の使用を中止してください。本来の性能を発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。
- お子さまに本製品の組み立てや撤収をさせないでください。
- チェアの組み立てや収納の際は、フレームの交差する箇所に指や手を挟まないように十分にご注意ください。
- 畳やフローリング、テント等の上で使用される場合は床面に傷がつく恐れがあります。
- 本製品を風雨があたる屋外で長期間設置しないでください。生地強度が低下し危険です。
- 本製品に強い衝撃をあてたり、収納した状態で重いものを載せないでください。変形し組み立てができなくなることがあります。
- 耐荷重を超える物を載せないでください。破損の恐れがあります。
- 濡れたまま放置しないでください。色が他の物に移ることがあります。

■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。
異常が見られた場合は使用しないでください。

☐ フレームに亀裂などがないか


☐ フレーム接合部にゆるみがないか

☐ 座面に破れがないか

■ 使用方法 ※組み立ての際は指を挟まないように注意してください。

○組み立て方法

- ①サイドフレームを持ってゆっくりと広げてください。その際、指を挟まないように注意してください。
- ②サイドフレームを下に押し広げてください。
- ③完成。



○収納方法

ひじかけを押さえながら座面横のサイドフレームを上に取り上げ、折り畳んでください。その際指を挟まないように注意してください。

■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を短めます。使用後や保管時は以下の点を参考にしてください。

- 使用後は汚れ、水分をふき取り陰干しし、完全に乾かしてください。汚れたまま、あるいは濡れたまま長時間放置すると色移りやカビが発生する可能性があります、また生地も劣化しやすくなります。
- 布地の汚れがひどい場合は薄めた中性洗剤をつけた布を軽く絞り表面を拭いてください。

■ 保管方法

- 雨露、粉塵、直射日光、紫外線、塩害を受けず高温、多湿ではない、風通しの良い乾燥した場所で保管してください。
- 火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。

■ 廃棄方法

- 廃棄方法は自治体の収集方法に従ってください。

■ アフターサービス

お問い合わせいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お問い合わせいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ 仕様・サイズ

(共通)

構造部材	金属(アルミニウム)	品番	1122788	品番	1122810
表面加工	粉体塗装	品名	フォールディング フィールドチェア	品名	フォールディング フィールドローチェア
張り材	ポリエステル [PVC・コーティング]	寸法	高さ77×幅55×奥行き54cm	寸法	高さ66×幅55×奥行き55cm
クッション材	ポリエチレンフォーム	座面の高さ	42cm	座面の高さ	34cm
耐荷重	約100kg	収納寸法	高さ80×幅15×奥行き54cm	収納寸法	高さ70×幅15×奥行き55cm

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont·bell

User's Manual

Folding Field Chair Series

Folding Field Chair Series

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.


Description

Offers excellent stability and roomy comfort in a foldable design.

The padded backrest, armrests, and seat deliver lasting relaxation even during extended use. A handle allows easy carrying when folded.

Components

*Product illustrated is Folding Field Chair.



Safety Warnings

Please read carefully.

WARNING! Under certain conditions, use of this product can result in injury, death, or property damage.

- To prevent falling over, do NOT lean back in the chair, lean on the arm rests, or sit in the chair incorrectly. Do NOT use the chair for any other purpose than sitting.
- Do NOT sit down forcefully or rock the seat back and forth. May cause damage or deformation.
- Ensure the load is evenly distributed across all legs of the product when sitting. Do NOT sit with your weight concentrated in one area, such as leaning back on the chair and lifting the front legs. May cause damage.
- For child use, ensure adult supervision to prevent the child from falling.
- Place this product on a firm, flat surface to help prevent tipping.
- Do NOT use this product near heat sources such as campfires. May cause deformation or damage.

CAUTION! Under certain conditions, use of this product can result in injury or property damage.

- Prior to each use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities. May negatively affect the performance of the product and impair function.
- Follow recommended care and storage instructions. Improper care and storage may lead to a decrease in performance.
- Do NOT let children to set up or take down the chair.
- Be careful not to pinch your fingers or hands in the frame joints when setting up or folding the product.
- Do NOT use this chair on top of tatami, flooring or inside a tent. The legs can damage the floor.
- Do NOT leave this product exposed to the elements for extended periods. May weaken the fabric and increase the risk of failure during use.
- Do NOT apply strong impacts to the product or place heavy objects on it while folded. May cause deformation and prevent proper assembly.
- Do NOT place objects exceeding the weight limit. May cause damage.
- Do NOT leave the product wet. Colors may transfer to other items.

Prior to use, inspect this product for: Stop using immediately if you notice any irregularities.

☐ Damage to the frame

☐ Loose joints


☐ Tears in the seat fabric

■ Directions

*Be careful not to pinch your fingers when setting up.

○ Setting up the chair

- ① Hold the side frames and unfold slowly. Be careful not to pinch your fingers.
- ② Push the side frames down until the seat fully opens.
- ③ Completed.



○ Folding the chair

Hold the armrests down and pull up the side frames to fold. Be careful not to pinch your fingers.

■ Care

Improper care and storage of this product can shorten its lifespan.

Follow the recommendations below to extend the lifespan of your product.

- After use, wipe off dirt and moisture, and dry completely in the shade. If stored wet or soiled, mold may grow, colors may transfer, and the fabric may deteriorate prematurely.
- If the fabric is heavily soiled, clean the product with a soft, damp cloth using mild soap.

■ Storage

- Store in a well-ventilated, dry place away from rain, dew, dust, direct sunlight, ultraviolet rays, and salt exposure.
- Do NOT place the product in a place where it will be exposed to high temperatures such as near a fire or heater. May cause deformation or damage.

■ Disposal

- Please follow local regulations regarding waste disposal.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specifications

(Series-wide)

Parts : Frame: metal (anodized aluminum)
Surface treatment: powder coating
Seat fabric: polyester [PVC coating]
Cushion: polyethylene foam

Weight capacity : 220 lbs 7.4 oz (100kg)

Style# : 1122788

Name : Folding Field Chair

Dimensions : H:77×W:55×D:54 cm

Height of seat : 42 cm

Folded dimensions : H:80×W:15×D:54 cm

Style# : 1122810

Name : Folding Field Low Chair

Dimensions : H:66×W:55×D:55 cm

Height of seat : 34 cm

Folded dimensions : H:70×W:15×D:55 cm

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

<https://www.montbell.com/>

44-5271-2601