

mont·bell

取扱説明書

シーフラッグ 本体

Sea Flag


重要 カヌー・カヤックへの取り付けには別売のマウントが必要です。別途お買い求めください。

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品は、海や湖での視認性を高める反射テープ付きフラッグです。フラッグに芯材を入れているため、無風時でも形状が崩れません。フラッグの高さを変えられるポールが付属します。※本製品はシーフラッグ本体のみです。カヌー・カヤックへの取り付けには別売のマウントが必要です。

■ 各部の名称



■ 安全上の注意 必ずお読みください


警告 場合により人が死亡または重傷を負う可能性が想定される内容です。軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品を使用することで遭難や衝突を防げるわけではありません。常に周囲の船舶、風や潮流などの状況に気を配ってください。
- 本製品はカヌー・カヤック用に設計されています。他の用途には使用しないでください。
- 本製品はカヌー・カヤック用です。クルーザーなどの船舶では使用できません。
- 雷の可能性があるときは使用を中止してください。落雷の恐れがあります。


注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- ご使用前に本商品が正しく取り付けられているか確認してからご使用ください。
- 間違えて組み立てた場合は本来の性能を発揮できないだけでなく、安全に漕ぐことが出来なくなることがあります。組み立て方法に従ってください。また再乗艇できるか必ず確認してください。
- 強風時、波が高い時などフィールドの状況によっては風であおられ危険になる場合があります。ご使用の際は注意してください。

- ショックコードを必要以上に伸ばさないでください。ポールが跳ね返った際、衝撃でポール先端が破損する恐れがあります（右図参照）。



- ポールは奥まで差し込んでください（右図参照）。
- 収納時にフラッグの芯材が折れないよう注意してください。




使用前の点検 使用にあたっては、毎回必ず次のことを確かめてください。異常が見られた場合は使用しないでください。

- ポールに亀裂などがないか
- リーシュにほつれなどがないか

■ 使用方法

○ 組み立て方法

① 右図のように、フラッグの芯材が下側になるように向きを合わせます。




ポールを組み立て、フラッグのスリーブとドロコードにポール

を通し、上部のドロコードをポールの先端にひっかかるように絞ります。下部のドロコードも絞り、フラッグを固定してください。

② リーシュのエンドのフックをカヤックに取り付けます。

○ フラッグの高さを変えて使用する場合



① フラッグを取り外し、ポールを必要な長さに折り畳みます。



② 上記の①の要領で、ポールの先端にドロコードがひっかかるように絞ります。



■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

○ ご使用後は、真水で砂や汚れを洗い流してから陰干しをしてください。汚れがひどい場合はぬるま湯と洗剤で洗い、洗剤が残留しないよう充分にすすぎを行ってください。乾燥後、ポールのジョイント部分に防錆潤滑剤をショックコードにかからないように塗布してください。(塩害防止効果のあるものをおすすめします)。

■ 保管方法

○ 保管場所は直射日光の当たらない風通しの良い場所を選んでください。

○ 本製品を火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。

■ 廃棄方法

○ 廃棄方法はお客様の自治体の収集方法に従ってください。

■ アフターサービス

お問い合わせいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お問い合わせいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ 仕様・サイズ

品番:1127634 品名:シーフラッグ 本体


ポール長:192cm(最大)、143cm(1回折り)、98cm(2回折り)、収納サイズ:52cm

■ その他


本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

○ 収納方法

ポールを収納する場合は真ん中付近から折りたたむようにします。こうすることにより、ショックコード全体に均一にテンションがかかり、ショックコードの寿命を伸ばすことができます。



フラッグを収納する際はドロコードをゆるめ、フラッグの位置を下げてから折りたたんでください。ポールの上からフラッグが大きくはみ出ないように注意してください。



mont·bell

User's Manual

Sea Flag

Sea Flag

Attention A mounting part (sold separately) is required for installation on canoes and kayaks.


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product. If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Description

Designed to increase visibility on the sea or lakes, the flag features a reflective strip for enhanced safety. A built-in frame keeps the flag shape even without wind, and a height-adjustable pole is included.

*This product only includes a flag and pole. Installation on a canoe or kayak requires a mounting part (sold separately).

Components



Safety Warnings

Please read carefully.



DANGER!

Under certain conditions, use of this product can result in major injury or death.


- Use of this product does NOT guarantee protection from wrecking and collision. Be aware of your surroundings, wind conditions, and currents.
- This product is designed for use with canoes and kayaks. Do NOT use this product for any other purposes.
- Use ONLY on canoes and kayaks. Do NOT use on cruisers or other boats.
- Do NOT use when there is a risk of lightning. May increase the danger of a lightning strike.




CAUTION!

Under certain conditions, use of this product can result in injury or property damage.

- Check that the product is installed correctly before use.
- Improper installation may negatively affect product's performance and compromise safe paddling. Carefully follow the installation instructions, and always confirm that you can safely re-enter the kayak.
- Be aware of the possibility that during strong winds, high waves, or other conditions, there is a risk that the product may be dangerously affected by the wind.
- Do NOT pull the shock cord more than necessary. Recoil can damage the pole as seen in the figure on the right.



- Fully insert pole sections. (See right Fig.)
- When storing, make sure not to bend the flag's frame.



Prior to use, inspect this product for:

Stop using immediately if you notice any irregularities.

Cracks or damage to the pole

Fray on the leash


■ Directions

○ Setting up the flag

① Orient the flag with the frame positioned at the bottom, as shown in the figure on the right.

Assemble the pole and pass it through the flag's sleeve


and drawcord loops. Tighten the top drawcord around the pole tip, then tighten the bottom drawcord to secure the flag in place.



② Connect the leash end hook to kayak's shock cord.


○ Taking down the flag

When taking apart the pole, fold starting at the middle (see illustration below). This extends the life of the shock cord by placing an equal amount of tension over the entire length of cord.






When storing, loosen the drawcord, lower the flag, and fold the pole.

Make sure the flag does not extend too far beyond the pole tip.



○ Adjusting the height of the flag



① Remove the flag and fold the pole to the desired length.

② Tighten the drawcord around the pole tip, in the same way as step ① of the "Setting up the flag" section above.

■ Care

Improper care and storage of this product can shorten its lifespan. Follow the recommendations below to extend the lifespan of your product.

- After use, rinse the product with fresh water to remove any sand or other debris and shade dry. For heavy soiling, wash with lukewarm water and mild soap, and rinse thoroughly. After drying, apply anti-rust lubricant to the pole joints, taking care to avoid the shock cord. A lubricant with salt-damage protection is recommended.

■ Storage

- Store in a well-ventilated place out of direct sunlight.
- Do NOT place the product in a place where it will be exposed to high temperatures such as near a fire or heater. May cause deformation or damage.

■ Disposal

- Follow local rules and regulations for proper disposal.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specifications

Style# : 1127634 Name : Sea Flag

Pole length : 192cm(maximum), 143cm(1 fold), 98cm(2 folds)

Packed size: 52cm *Stuff sack included.

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

<https://www.montbell.com/>

44-6516-2509