

## ■ お手入れ方法

間違っただけのお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- ご使用後は水洗いをして泥などを落とし、乾燥させて、金属部分に市販の防錆油等を塗布してください。
- ベルトやバックルなどにキズや破損等がないかを確認してください。
- アイゼンの爪が摩耗しているときは金工ヤスリ等で削ってください。

## ■ 保管方法

- 火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。
- 保管場所は直射日光の当たらない風通しの良い場所を選んでください。

## ■ 廃棄方法

- 廃棄方法はお住まいの自治体の収集方法に従ってください。

## ■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違っただけのお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理をさせていただきます。

## ■ 仕様

品番：1129613  
品名：スノースパイク6 クイックフィット  
サイズ：爪の長さ23mm  
素材：(アイゼン本体) S55C炭素鋼  
(ベルト) エラストマー

対応靴サイズ：S(21.5~23.0cm)、M(23.0~26.5cm)、L(26.5~30.0cm)  
※靴の形状によっては対応サイズでも装着できない場合があります。  
※フラットソールの靴には対応しません。

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

# mont-bell

## 取扱説明書

# スノースパイク6 クイックフィット

## Snow Spike 6 Quick Fit

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。


ただし、本説明書は本製品の基本的な使用方法を示すものであり登山の安全システムを解説するものではありません。安全な条件のもとで十分な練習を行い、正しい使用方法を習得してください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長

本製品は夏の雪渓や、冬の低山歩行用に最適な軽アイゼンです。安全性の高い独自のラチェットバックル(特許取得済)で素早い装着が可能。さらに雪が団子状に付着しにくいアンチスノープレートを特長としています。

## ■ 各部の名称



## ■ 安全上の注意 必ずお読みください

**⚠ 危険** 人が死亡または重傷を負う危険が差し迫って生じることが想定される内容です。

○登山は常に潜在的な危険をはらんでいます。たとえ用具の正しい選択、使用、お手入れ、保管を行っても傷害や死亡事故などに至る危険性を完全に排除することは出来ません。個人の責任において登山を行ってください。(株)モンベルでは本製品の誤った使用に起因する損害や傷害、死亡事故に対していかなる責任をも負いません。

○本製品は簡易アイゼンです。本格的な雪山登山には使用しないでください。

○本製品は登山専用のアイゼンです。その他の用途には使用しないでください。

**警告** 場合により人が死亡または重傷を負う可能性が想定される内容です。  
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品に対応する靴のサイズでご使用ください。対応サイズ外の場合は本来の性能が発揮できない恐れがあります。
- 使用方法をご覧のうえ、靴に合わせてサイズを正しく調節してください。正しく調節しないと本来の性能が発揮できない恐れがあります。
- フラットソールの靴には合いません。土踏まず部が凹状、かかと部が凸状になっているかを確認してからご使用ください。
- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に能力が発揮できない恐れがあります。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合には直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。
- アイゼンの底についた雪や雪の固まりは常に取り除いてください。放置すると爪が効かず、本来の制動力を発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。

**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

- 携行する際は左右のアイゼンの爪を内側に重ね、付属の収納袋に入れてください。
- アイゼンを使用する際は十分に歩行練習などを行ってください。アイゼンを装着していないときに比べ爪を引っ掛けて転倒する可能性が高くなります。
- 本製品は氷雪上の滑り止め用具です。氷雪以外で使用すると爪が折れ曲がったり、アンチスノープレートが傷ついたり破損することがあります。

## ■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。


- 爪やアンチスノープレートにひびや変形が見られないか
- ベルトに破損などがないか
- バックルは正しく機能するか

## ■ 使用方法

本製品の性能を十分に発揮させるために、使用者の靴にしっかり合うようにサイズ調節を行ってください。不適切なサイズ調節や、装着ではアイゼンが靴から外れたりして危険です。サイズ調節は必ずフィールドに行く前に行ってください。


### ○ 幅の調整方法

- ① 付属の六角レンチを使用し、本製品の底側にあるサイズ調整用ボルトを緩め、幅いっぱいを広げてください(図a)。
- ② ご使用になる靴と本製品を合わせます(図b)。その際本製品の2箇所の突起が靴底のかかと部分に合うようにします(図d)。




2

- ③ 本製品の幅を靴の幅に合うところまで狭めてください。その際、本製品が靴にピッタリと合うまで狭めます(図c)。
- ④ 付属の六角レンチを使用し本製品の底側にあるサイズ調整用ボルトを締めてください。






### ○ 装着方法


- ① 本製品には左右があります。装着するときは靴底の雪や土をよく取り除き、ラチェットバックルの付いている方が外側になるよう装着します(P.1 装着例参照)。
- ② アイゼンの2箇所の突起が靴底のかかと部分に合うようにします(図d)。ヒールベルトを靴のかかと部へ回します。この際、ヒールベルトがかかとの一番上になるようにしてください(図e)。



- ③ 後部ラチェットバックルに後部ベルトの先端を通します(図f)。
- ④ 締付けレバーを矢印(実線)の方向に動かしてください(図g)。締付けレバーを数回動かすことで徐々に締まっていきます。前部ベルトも同様に締めてください。  
※締めすぎると血行障害を引き起こし、低温下では凍傷の原因になることもあります。  
※バックルやベルトが破損する恐れがありますので、必要以上に締付けしないでください。(目安として、締付けレバーを動かして締付けレバーのツメが滑りだすと締め過ぎです)。
- ⑤ 締めすぎた場合は開放レバーを矢印(実線)の方向に左右同時に動かし(図h)、ベルトをゆるめてから締付けレバーを再度調整してください。




- ⑥ サイズが小さめの靴に装着する場合、上記の装着方法では十分にベルトを締付けできない場合があります。靴の種類にもよりますが、23.5cm前後以下の靴の場合は前部ベルトを後部ラチェットバックルに、後部ベルトを前部ラチェットバックルに通し、ベルトを交差させるように取り付けてください(図i)。



### ○ はずし方

- ① 前部と後部のラチェットバックルの開放レバーを、それぞれ矢印の方向に左右同時に動かし(図h)、ラチェットバックル全体を持ち上げるようにしてラチェットバックルからベルトを抜いてください。  
※現場で使用する前に説明書なしで手早く着脱できるよう練習してください。  
※部分的に緩んだりせず、左右対称で均等に締まっているかを確認してください。

※装着後、必要以上に前部・後部ベルトが余る場合は、余り分をハサミ等でカットすることをお勧めします。その際、装着した状態で5cm以上末端は残すようにしてください(図j)。図の様にコーナーを少しカットすることで、ラチェットバックルに入れ易くなります。



3


## ○ Taking off

- ① Lift both of the release levers and lift the ratchet buckle to pull it off of the belt (see Fig. h).

\*Practice before hand so that you are able to take off and put on the crampons without this manual.

\*Check for slack in both the left and right straps and make sure they are secured.

\*After all fit adjustments have been made and there is extra belt, we recommend cutting off excess belt. If you do decide to cut the belt, we recommend leaving at least 5cm (see Fig. f). It is also recommend that you trim the corners at an angle (see Fig. f).



## ■ Care

Improper care and storage of this product can shorten its lifespan. Follow the recommendations below to extend the lifespan of your product.

- Wash away stains and soiling with water. Avoid direct sunlight and allow to air dry in a cool, well ventilated area before applying a corrosion inhibitor.
- Check for damage to the belts and buckles.
- When points have become worn, use a file to sharpen.

## ■ Storage

- To prevent deforming and damage to the shelter, do NOT store near heat sources.
- When storing for an extended period of time, store in a well ventilated, cool, dry place out of direct sunlight.

## ■ Disposal

- Please follow local regulations regarding waste disposal.

## ■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at our discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

## ■ Specifications

Style #: 1129613

Name: Snow Spike 6 Quickfit

Size: Point length 23mm

Material: (Crampon) carbon steel, (Belt) Elastomer

Shoe size compatibility :S (21.5 - 23.0cm), M (23.0 - 26.5cm), L (26.5 - 30.0cm)

\*Shoes may not fit due to shape, even if within size range.

\*These micro crampons are NOT compatible with flat soled shoes.

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

www.montbell.com

44-2503-1802

mont-bell

User's Manual

# Snow Spike 6 Quickfit

## Snow Spike 6 Quickfit

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.


However, the information in this User's Manual only covers the basic use of these crampons and does NOT cover outdoor safety. We recommend practicing the use of these crampons under safe and controlled conditions.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

## ■ Description

Perfect for travel over unmelted snow in high elevations in summer or small mountains and hillwalking in winter, these micro crampons are extremely compact. Utilizes a Montbell original design to increase safety and prevent accidental release, and anti-snow plates prevent snow from clumping on the underside of the crampon.

## ■ Components



## ■ Safety Warnings! Please read carefully.

**⚠ DANGER!** Under certain conditions, use of this product can result in major injury or death.

- Mountaineering and rock climbing are inherently dangerous activities. Even if these crampons are used, cared for, and stored correctly, it will not completely eliminate the risk of major injury or death. You are responsible for your own actions and decisions. Montbell Co. LTD is not liable for damages or accidents resulting in injury or death resulting from improper usage.
- This product is a micro crampon. It is NOT designed for use in alpine conditions.
- These micro crampons are NOT designed for any other purpose than for trekking and hiking.



**! WARNINGS!** Under certain conditions, use of this product can result in injury, death, or property damage.

- Make sure this product is correctly sized to match your shoes. This product will not perform as intended if not sized correctly.
- Follow the instructions for correct fitting. This product will not perform as intended if not fitted correctly.
- These micro crampons are NOT compatible with flat soled shoes. Check to make sure your shoe has an concaved arch and the heel is prominent.
- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- Prior to use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.
- Routinely clear snow from the crampons. Accumulated snow can prevent the crampon's points from performing as intended.
- Please follow recommended care and storage instructions. Improper care and storage can lead to decrease in performance.

**! CAUTION!** Under certain conditions, use of this product can result in injury or property damage.

- For transporting, use the included stuff sack and stack the crampons so the points face each other.
- Please practice walking while wearing crampons. The crampon's points can make it difficult to walk, increasing the chances of tripping or falling.
- This crampon is meant for use on ice and snow. The points can bend or break and the anti-snow plates can become damaged when used on surfaces without ice or snow.

**■ Prior to use, inspect this product for:**

Whether or not there is damage or deforming on the points or anti-snow plates.


Whether or not the belt is damaged

**■ Directions**


In order for these crampons to perform as intended, they must be correctly sized to your shoes. If not sized or fitted correctly to the shoes, there is a possibility the crampons can become loose and separate from your shoes during use. Perform sizing and fitting adjustments before use.

**○ Adjusting crampon width**

- 1 Use the hex wrench to loosen the sizing bolts and adjust the crampon to its widest setting (see Fig. a)
- 2 Place your shoe in the crampon (see Fig. b). Make sure the crampons two ridges are in contact with the shoes heel (see Fig. d).




- 3 Adjust the width of the crampon to match the width of the shoe. When doing so make sure the crampon is in good contact with the shoe (see Fig. c).
- 4 Use the hex wrench to tighten the sizing bolts, locking the fit of the crampon in place.






**○ Putting on**

- 1 Match crampons to left and right shoes. Before putting on, clear off any snow or dirt on the bottom of the sole. Make sure the crampon's buckle is positioned on the outer side of the shoe (see Page 1).
- 2 Make sure the crampon's two ridges are in contact with the shoes heel (see Fig. d). Wrap the heel belt around the heel of the shoe. Make sure the heel belt is placed at the highest point of the heel (see Fig. e).



- 3 Wrap the instep belt over the instep and insert it into the instep's ratchet buckle (see Fig. f).
- 4 Repeatedly lift the ratchet lever to tighten the belt (see Fig. g).
  - \*If fit is too tight, the belt can cut of blood circulation which can result in frostbite in cold weather conditions.
  - \*Tightening the belt too much can damage the buckle and the belt. (As a general idea, if the ratchet lever starts to slip on the belt, the fit is too tight).
- 5 If belt is too tight, lift both of the release levers to loosen the belt and readjust (see Fig. h).



- 6 In some cases if the boot is too small to secure in the crampon, it may be necessary to cross the instep and ankle belts to attain proper fit. Use this method of crossing belts for shoes under 23.5cm (see Fig. i).

