

## ■ 仕様・サイズ

【品番】	【品名】
#1133299	チャチャパック30
#1133300	チャチャパック30 Women's <b>女性用</b>
#1133301	チャチャパック35
#1133302	チャチャパック35 Women's <b>女性用</b>
#1133303	チャチャパック45
#1133304	チャチャパック40 Women's <b>女性用</b>

女性用は、機能、デザインはそのままに、背面長、ヒップベルト、ショルダーハーネスを女性の体に合わせて設定しています。身長145～165cmくらいまでの方に最適なモデルです。

## 【素材】

正面：100デニール・バリスティック®ナイロン・リップストップ [ウレタン・コーティング]

底部：210デニール・バリスティック®ナイロン・リップストップ [ウレタン・コーティング]

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

# mont·bell

## 共通取扱説明書

# チャチャパック シリーズ

## Cha-Cha Pack Series

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長

大小さまざまなポケットを装備し、収納力に優れた1気室の中型パックです。日帰りのトレッキングや1泊2日の小屋泊まり登山など、幅広い用途で使用していただけます。専用パックカバー付き。

## ■ 各部の名称

\*写真は45Lです。



## ■ 安全上の注意

**必ずお読みください**



**警告** 場合により人が死亡または重傷を負う可能性が想定される内容です。軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に能力が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。



**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。

## ■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。異常が見られた場合は使用しないでください。


- 本体に破れがないか
- バックルなどに破損がないか

## ■ 使用方法

### ○ フィッティングの手順

パックがジャストフィットしている状態とは、バックパネルとショルダーハーネスが体に隙間無く接している状態のことをいいます。ご使用にあたっては、ご自身の体格に合わせて、適切なフィッティングを行ってください。

本製品の各バックルに通したテープをあらかじめ適度に緩めておきます。また、実際の使用状態での正しいポジションを得るために、まず 10kg 程度の荷物をバックに入れます。



① パックを背負い、腹部を圧迫しないように腰骨部分でヒップベルトを締める。

② ショルダーハーネスが体にフィットするようにショルダーストラップを引く。

③ このとき、パックと背中との間に隙間があるようならフレームを調節してください。


④ ヒップスタビライザーを引いて底部の左右の揺れを防ぐ。

⑤ ショルダースタビライザーを引き、上部の重心を体に引き寄せ安定させる (30Lを除く)。

⑥ ショルダーハーネスを安定させるためにチェストサポートを留める。

### フレームの調節

本製品に内蔵されているアルミフレームは、あらかじめ体の背面のカーブに合わせて曲げています。ほとんどの場合はそのままご使用いただけますが、本製品と体の間に隙間がある場合は以下の手順でアルミフレームを曲げてください。



- 荷物を取り出して空荷の状態にして、本製品に内蔵されているアルミフレームを曲げます。体との隙間がなくなるように脚などを使って曲げていきます。

※アルミフレームは本製品から取り出さず本体ごと曲げてください。


※一度に大きく曲げるのではなく、少しずつ曲げてください。

- アルミフレームの調節後、手順を①からやり直します。


以上で、本製品の基本的なフィッティングは完了です。ただし、各テープ類の長さは身に着ける服によっても変わりますので、その都度の微調節が必要です。苦しくならない範囲でしっかり締めてください。

### ○ トレールウォーターパック(別売)取り付け方法

トレールウォーターパックは荷物を降ろさずに行動しながら水分補給ができる、チューブで給水するソフトタイプのボトルです。装着の際はトレールウォーターパック付属の取扱説明書も併せてご覧ください。



トレールウォーターパックのスライドパーツのフックを荷室内上部の図のループに掛けて装着し、本体側通し穴を通して荷室の外に出し、チューブを出します。



トップリッド側の通し穴からチューブを外に出し、ショルダーハーネスのループ(A)に通し、飲み口の位置を調節します。チェストサポートに付いている固定用クリップ(B)も併用します。

### ■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- 汗による汚れや泥の汚れは水で軽く洗い流した後中性洗剤を含ませたスポンジでブラッシングをし、洗剤を洗い流してから陰干ししてください。
- ドライクリーニングや洗濯機による洗濯はしないでください。生地を傷める恐れがあります。
- 乾燥機を使用しないでください。製品の寿命を縮める恐れがあります。
- 長期の使用により、はっ水性能(水を弾く力)が低下した場合は別売のはっ水スプレー等をご使用ください。

### ■ 保管方法

- 高温になる場所を避け、風通しの良い場所に保管してください。
- ガンリンやシンナーと一緒に保管しないでください。

### ■ 廃棄方法

- 廃棄方法はお客様の自治体の収集方法に従ってください。

### ■ アフターサービス

お問い合わせいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お問い合わせいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

## ■ Specifications

[Style]	[Name]
#1133299	Cha-Cha Pack 30
#1133300	Cha-Cha Pack 30 Women's
#1133301	Cha-Cha Pack 35
#1133302	Cha-Cha Pack 35 Women's
#1133303	Cha-Cha Pack 45
#1133304	Cha-Cha Pack 40 Women's

Women's models feature the same design and functionality as Men's models, but with an adjusted hipbelt, shoulder harness, and back length to better fit the female form. Ideal for heights from 145cm to 165cm.

### 【Material】

Main : 100-denier urethane coated rip-stop nylon  
Bottom : 210-denier urethane coated rip-stop nylon

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN  
<https://www.montbell.jp/>

mont-bell

User's Manual

# Cha-Cha Pack Series

## Cha-Cha Pack Series

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.


If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

## ■ Description

This mid-sized backpack has many various sized pockets for organizing your trail gear. Great for trekking or overnight trips, the Cha-Cha Pack is an excellent multipurpose backpack. Stow-away rain cover included.

## ■ Components

\*45L model



## ■ Safety Warnings! Please read carefully.

**⚠ WARNING!** Under certain conditions, use of this product can result in injury, death, or property damage.

- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- Please follow recommended care and storage instructions. Improper care and storage can lead to a decrease in performance.

**⚠ CAUTION!** Under certain conditions, use of this product can result in injury or property damage.

- Prior to use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.

## ■ Prior to use, inspect this product for:


- Damage to the fabric and straps     Damage to the buckles

## ■ Directions

### ○ Fitting Process

The correct fit is achieved when the back panel and shoulder harness fit the body without any gaps. When using the pack, ensure that it is properly fitted according to your own physique.

Before starting, unbuckle and loosen all straps. To simulate conditions during actual use, load about 10kg of weight into the backpack.



1 Put the pack on, then fasten the hipbelt with it sitting on the hipbone.

2 Pull the shoulder straps so that they tighten around your shoulders and armpits.

3 If there are gaps between the backpack and your back, make adjustments to the 3D Fit Aluminum Frame.


4 Pull the hipbelt stabilizers to prevent the backpack from shifting left and right.

5 Pull the load lifters to draw the backpack's center of gravity in closer to your body (except for 30L models).

6 Fasten the sternum strap to secure the shoulder harness in place.

### Adjust the 3D Fit Aluminum Frame

The 3D Fit Aluminum Frame inside this product has been pre-bent to fit the curve and shape of the back. In most cases, it can be used as it is. If there are any gaps between the backpack, your shoulders and back, please use the following instructions to make any necessary adjustments.



Remove all items inside the backpack and be sure to perform any adjustments when the backpack is empty. Check the location of the 3D Fit Aluminum Frame (see illustration below) and bend it while inside the backpack using your legs.


- Do not remove the 3D Fit Aluminum Frame.
- Make sure to bend the left and right sides of the frame at the same time.
- Make minor, gradual adjustments to the frame and avoid swift, major adjustments.

After adjusting 3D Fit Aluminum Frame, start over from step ①.


The fitting of your backpack is now complete. Depending on what you wear you may need to make minor adjustments to the shoulder straps, load lifters, and hipbelt straps. Fasten straps so that they are secure, but do not cause discomfort.

### ○ This pack is compatible with Trail Water Pack (sold separately)

A hydration bladder with a tube that allows you to drink when you're on the go, without needing to put your backpack down.



Hang the hook connected to the Trail Water Pack from the loop located inside the backpack. Pull the tube through the hose port.



Pass the tube through the loop on the shoulder harness (A) and adjust the position of the mouth piece. The tube can be clipped onto the sternum strap (B).

### ■ Care

Improper care and storage will shorten the lifespan of this product. Please review the following instructions for care and storage.

- To clean stains and soiling, lightly rinse off and use a mild soap with a sponge to brush away any remaining residue. Rinse off and dry in the shade. Do NOT dry clean. This can damage the product's fabric.
- Do NOT dry clean or wash in a washing machine. This can damage the product's fabric.
- Do NOT dry in a dryer. Shorten the product's lifespan.
- Water repellency will decrease over time. To restore water repellency, first clean any residues from the fabric surface and then apply a water repellent spray (sold separately).

### ■ Storage

- Store in a well-ventilated, cool, dry place.
- Do NOT store together with gasoline or paint thinner.

### ■ Disposal

- Please follow local regulations regarding waste disposal.

### ■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at montbell's discretion. This warranty does not cover damage caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.