

# mont·bell

## 共通取扱説明書

# カーボン フォールディングポールシリーズ


この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長

超軽量でコンパクトに収納できるフルカーボンシャフトの折り畳み式ポールです。グリップを長めに設計し、握り位置を変えることでさまざまな状況に対応できます。4サイズ展開で、身長に合わせたモデルをお選びいただけます。折り畳み時に干渉しない半円形の固定式トレッキングバスケットを備えています。

## ■ 各部の名称



## ■ 安全上の注意 **必ずお読みください**

**警告** 場合により人が死亡または重傷を負う可能性が想定される内容です。  
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品は登山用です。これ以外の目的では使用しないでください。
- 本製品は軽量コンパクト性を重視したバランス補助用のポールです。体重をあずけるような使い方はお避けください。
- 本製品は登山用ピッケルではありません。グリセードやクライミングの支点には絶対に使用しないでください。また、両端を強い力で引くとグリップやシャフトが抜けてしまう可能性があります。人や荷物の引き上げには使用しないでください。
- 岩場など手を使って確保が必要な場所では、バックパックに収納するなどして使用しないでください。

- 落雷の恐れがあるときは使用しないでください。
- ご使用時にシャフトの固定が不十分だと転倒などの原因となり危険です。ご使用前は必ず固定状態を確認してください。行動中も緩みがないかを確認してください。
- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、充分に保護能力が発揮できない恐れがあります。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。

**⚠ 注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

- 使用中は振り回さないでください。周囲の人や物に危害を加える恐れがあります。
- 横からの強い荷重をかけないでください。構造上、横方向からの荷重には縦方向ほどの強度はありません。
- 使用しないときは、石突きに必ず付属のポイントプロテクターを装着してください。
- ポールに全体重をかけることはお避けください。ケガやポールが破損する恐れがあります。
- お子さまや、ご年配の方がご使用になる際は、周囲の人がシャフトが固定されていることを確認してください。
- 先端のポイントプロテクターは消耗品です。すり減った場合は速やかに専用のポイントプロテクターに交換してください。
- 高温になる場所に放置しないでください。グリップが変形したり、やけどをする恐れがあります。
- 極度の低温下ではシャフトが凍ったり、各部の機能が低下することがあります。
- グリップは素材の特性上、保水して凍ったり、雪が付着することがあります。凍る可能性のある状況での使用はお避けください。

## ■ 使用前の点検


使用にあたっては、毎回必ず次のことを確かめてください。

- ひびや変形が見られないか
- シャフトのロックは確実にできるか
- テンションコードに緩みがないか

## ■ 使用方法



コースや地形に応じてグリップを握る位置、ストラップの長さを適切に調節してください。

- **長さの目安** (使用する状況に応じてグリップの握る位置を調節してください。)





## ○ 組み立て方法

- ① グリップを握り、各シャフトを図のように伸ばします。
- ② テンションコードのエンドループに指を通し、結び目が出るまで引いて各シャフトを繋ぎます。
- ③ テンションコードの結び目を、コードストッパーの切れ込みに引っかけて固定します。




### ⚠ 注意

3カ所のシャフト接続部分が確実に接続されている事を確認してください。



## ○ 収納方法


- ① テンションコードの結び目を外してロックを解除します。
- ② 上段、中段、下段シャフトのジョイントの接続を外し、結束用ベルトで固定します。



## ■ グリップの握り方とストラップの調節方法


### ○ グリップの握り方

- ① 下方向からストラップに手を通します。
- ② ストラップとグリップを図のように握ります。



### ○ ストラップの調節方法

- 短くする時  
テープを引くことで短くなります。
- 長くする時  
バックルを起こすとストラップが開放され、長さの調節ができます。



ストラップの向きの調節  
出荷時には全て右手用に設定されています。

左専用

右専用



左手で使用するときにはバックルからストラップを一度外し、逆向きに一回ねじることで、使用しやすくなります。


## ○ ポイントプロテクター

独自構造の脱着しにくいラバー製キャップです。移動時や植生にダメージを与える可能性のある登山道や木道では必ず装着して使用してください。また、雪上では取り外して使用してください。

※ポイントプロテクターは消耗品です。傷んだ際は交換してください。

### ■ 取り付け方

カチツと音がするまで、ポールの石突きをしっかり差し込んでください。奥まで入れないと脱落する恐れがあります。



## ■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- ストラップが汚れた際は、中性洗剤で洗ってください。洗浄後は十分にすすぎ、完全に乾燥させてください。
- ご使用後はシャフトを図のようにして汚れをよく落とし、完全に乾燥させてください。



## ■ 保管方法

- ご使用後はシャフトを上記のお手入れ方法の図のように折り畳んで保管してください。ロックを解除せずに保管するとテンションコードを伸ばしてしまう恐れがあります。
- 本製品を長期間使用せずに保管する場合は、直射日光の当たらない風通しの良い場所に保管してください。
- 火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。

## ■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

## ■ オプション(別売) 本製品は下記の別売のオプションを利用することができます。

- ポイントプロテクター 交換用のキャップです。
- フォールディングポールケース ポールを2本収納できます。

## ■ 仕様・サイズ

品番: 1140273	品名: カーボン フォールディングポール 100	使用長: 90~100cm
品番: 1140274	品名: カーボン フォールディングポール 105	使用長: 95~105cm
品番: 1140275	品名: カーボン フォールディングポール 113	使用長: 103~113cm
品番: 1140276	品名: カーボン フォールディングポール 120	使用長: 110~120cm

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

株式会社 **モンベル** 本社 〒550-0013 大阪市西区新町2-2-2 モンベルホームページ <https://www.montbell.jp/>  
商品についてのお問い合わせはカスタマー・サービスまで Tel. 06-6531-3544 フリーコール: 0088-22-0031

# mont·bell

## User's Manual

# Carbon Folding Pole Series


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

## ■ Description

Featuring full-carbon shafts and a foldable design, this ultralight pole packs down compactly to fit even in a small daypack. The extended grip allows flexible hand positioning to adapt to various terrain. Available in four sizes to match different heights. The semicircular basket fits neatly along the shaft for efficient packing.

## ■ Parts



## ■ Safety Warnings Please read carefully.

**⚠ WARNING!** Under certain conditions, use of this product can result in injury, death, or property damage.

- This product is for hiking and trekking use only. Do NOT use this product for any other purpose for which it was not designed.
- This product features a lightweight, compact design and is intended for balance assistance. Do NOT use it to support your full body weight.
- Do NOT use as an alpine axe, for glissading or as an anchor for climbing. Do NOT pull strongly on both ends of the pole as the shaft or grip can come apart. Do NOT use the pole for pulling up people or luggage.
- In rocky terrain where climbing is necessary, store poles in your backpack or its stuff sack to free up your hands.
- Do NOT use if there is a risk of lightning.

- If the shaft is not properly secured, it can come apart or slide closed during use and result in a falling accident. Prior to use, check to see if the shafts are properly locked in place and periodically check for loosening.
- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair function.
- Prior to each use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities. May negatively affect the performance of the product and impair function.
- Follow recommended care and storage instructions. Improper care and storage may lead to a decrease in performance.

**⚠ CAUTION** Under certain conditions, use of this product can result in injury or property damage.

- Do NOT swing or wave poles around. May result in injury or property damage.
- Do NOT apply strong lateral forces to the pole, as it is designed to support vertical loads and less resistant to side forces.
- When not in use, always attach the point protector included with the product.
- Do NOT place your full weight onto the pole. May result in injury or damage.
- When this product is used by a child or an elderly person, have someone nearby check that the shafts are securely locked.
- The point protector wears out with use. Replace it as soon as possible when it becomes worn.
- Do NOT leave the product in high temperatures. May cause the grip to deform or result in burns.
- At very low temperatures, the shaft may freeze and the performance of certain components may decrease.
- Due to the characteristics of the material, the grip may retain water and freeze, or snow may adhere. Avoid using this product in freezing conditions.


**■ Prior to use, inspect this product for;** Stop using immediately if you notice any irregularities.

- Cracks or deformation
- Securely locked shafts
- Securely tightened tension cord

**■ Directions**

Adjust the holding position and strap length according to the terrain and trail conditions.

- **Optimal pole length** [Change the holding position depending on the situation.] \_\_\_\_\_



Hold the pole so the angle between the pole and your arm is about 90 degrees.


Hold the pole shorter to make it easier to place the pole in front of you.

Hold the pole longer to help maintain an upright, comfortable posture.



Hold the uphill-side pole shorter and the downhill-side pole longer.

## ○ Assembling the pole

① Hold the grip and align the shafts as shown below.




② Thread your finger through the end loop and pull the tension cord until the knot comes out, connecting the shafts together.



**CAUTION**  
Ensure all three shaft joints are securely connected.

③ Pass the cord through the cord stopper slit and lock the knot in place.




## ○ Collapsing the pole

① Release the tension cord knot from the slit to unlock.



② Disconnect all shaft joints and secure them together with the hook-and-loop strap.





## ■ Holding the grip and adjusting strap length

### ○ Holding the grip

① Put your hand through the strap from below.

② Hold the strap and grip as shown in the figure.




### ○ Adjusting strap length

**To shorten**  
Pull the strap end.



**To lengthen**  
Lift the buckle to release the strap and adjust accordingly.




**Changing strap orientation**  
The strap is preset for right-hand use.

Left Hand	Right Hand

To use it with the left hand, remove the strap from the buckle, twist it 360 degrees as shown in the figure, and reinsert it through the buckle.

## Point protector

A rubber cap with a proprietary design to help prevent accidental detachment. Always keep it attached when transporting, walking on boardwalks, or hiking on trails where there is a risk of damaging vegetation. Remove before using on snow. \*Point protectors will wear out and eventually need to be replaced.



### ■ Attaching

Push the point protector firmly onto the pole tip until it clicks into place. If not properly attached, point protector may become dislodged and fall off.

### ■ Care

Improper care and storage of this product can shorten its lifespan.

Follow the recommendations below to extend the lifespan of your product.

- If the strap becomes dirty, clean with a mild detergent. Rinse thoroughly and allow it to dry completely.
- After use, disconnect the shafts as shown in the figure, thoroughly clean off dirt, and dry completely before storing.



### ■ Storage

- After use, fold up loosely for storage (as shown above). Storing the product with the tension cord locked may cause the cord to stretch unnecessarily.
- When storing for an extended period of time, store in a well-ventilated place out of direct sunlight.
- Do NOT place the product in a place where it will be exposed to high temperatures such as near a fire or heater. May cause deformation or damage.

### ■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

### ■ Accessories (sold separately)

The following accessories are available for use with this product.

- **Point Protector**  
Replacement rubber cap.
- **Folding Pole Case**  
Stores up to two poles.

### ■ Specifications

<b>Style #</b> : 1140273	<b>Name</b> : Carbon Folding Pole 100	<b>Usable length</b> : 90~100cm
<b>Style #</b> : 1140274	<b>Name</b> : Carbon Folding Pole 105	<b>Usable length</b> : 95~105cm
<b>Style #</b> : 1140275	<b>Name</b> : Carbon Folding Pole 113	<b>Usable length</b> : 103~113cm
<b>Style #</b> : 1140276	<b>Name</b> : Carbon Folding Pole 120	<b>Usable length</b> : 110~120cm

All product specifications and design are subject to change without prior notice.  
Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN  
<https://www.montbell.com/>