mont·bell

共通取扱説明書

ホライゾンパドル シリーズ

Horizon Paddle Series

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用の前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。
なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品は長さ調節が可能なスタンドアップパドルボード用のパドルです。

保護者の方へ

- お子さまがご使用になる際は、保護者の方が本説明書をよくお読みになり、お子さまが理解できるようにご説明ください。
- 本製品の操作が出来ないお子さまは絶対に使用しないでください。ケガや事故の恐れがあります。

■ 各部の名称

※イラストはホライゾンパドル アルミです。

■ 安全上の注意 必ずお読みください

⚠ 危険 人が死亡または重傷を負う危険が差し迫って生じることが想定される内容です。

◯スタンドアップパドルボードは、場合によっては使用者や周囲の人を危険に陥れたり、死傷事故を誘発する可能性のあるスポーツです。本製品またはそれに係わる製品を使用する方は、傷害を負ったり、死亡する場合もあり得ることを理解しておかなければなりません。また、事故を防止するためにも、本製品を使用する前には必ず本説明書を熟読し、その指示に従ってください。
◯本製品は製品の特性上、本体に強い負担がかかるような激しい使用方法には適しません。
◯沿岸では潮の干満や潮流の速さも十分に考慮してください。また、湖、大河、沿岸等で使用する際は、気象の変化により思いもよらぬ突風、強風が吹く場合があります。人力に頼っているスタンドアップパドルボードの特性をよく理解し、無理せず安全にお使いください。

⚠ 警告 場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

◯本製品はスタンドアップパドルボード用に開発された漕ぐためのものです。本来の用途以外に使用しないでください。
◯周囲の人や物に危害を加える恐れがありますので、使用する際はまわりに気をつけてください。
◯安全な場所で操作方法を十分に練習してから使用してください。操作に不慣れだと傷害を負ったり、事故の恐れがあります。
◯本製品の改造はしないでください。傷害を負ったり、事故、破損の恐れがあります。

⚠ 注意 人が傷害を負ったり物的損害の発生が想定される内容です。

◯お子さまがご使用になる際は、保護者の方が本説明書をよくお読みになり、お子様が理解できるようにご説明し、使用方法を理解したかどうかを確認のうえ、必ず保護者の監視下でご使用ください。お子さま同士や、一人だけでの使用は絶対におやめください。
◯本製品は軽量で丈夫な素材で作られていますが、浅瀬などで岩などに激突するような場所で使用すると破損する恐れがあります。
◯長期間太陽光にさらすと本製品が紫外線により退色や劣化する恐れがあります。
◯高い水圧を受けたときや、水中に長時間沈めているとシャフトの中に水が入り、パドルの浮力が低下する恐れがあります。

■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。
異常が見られた場合は使用しないでください。

□ 磨耗やひび割れ、故障やその兆候などが無いか　□ 長さ調節パーツが正しく機能するか

■ 使用方法

○パドルの長さの調節方法

長さ調節パーツのレバーの開閉でパドルの長さを変えることができます。
パドルの長さは使用目的により変わりますが目安として身長に15～25cm程度を足した長さです。
長さ調節をする際はグリップの前面とブレードの前面を同じ向きにそろえてください。





※ホライゾンパドル カーボンとホライゾンパドル グラスはシャフトに溝が付いており、グリップ（上段シャフト）とブレードの取り付け向きがずれません。
※パドルのグリップの凹み（前面）を進行方向に向けて握ってください。
※イラストはホライゾンパドル アルミです。



※長さ調節レバーがゆるいと上段シャフトが抜け落ちる可能性があります。長さ調節レバーを閉めた際に、ゆるい場合は長さ調節レバーを左図のように時計回りに回して、ネジを締めてください。強く締めすぎると締め具が破損する場合があります。

⚠注意

調節幅は（STOP）の表示までの範囲で調節してください。（STOP）の表示以上に伸ばして使用するとジョイント部に過度の負荷がかかり、破損の原因となります（右図）。



■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。
使用後や保管時は以下の点を参考にしてください。

○ご使用後は汚れをよく落とし、上段シャフトを外して全体を真水で洗って乾燥させてください。
○本製品を海水で使用し長期間組み立てたままにしておくと塩分が結晶化してジョイント部分が固着する恐れがありますので、海での使用後は上段シャフトを外して全体を真水で十分に洗い、塩分を取り除いてください。

■ 保管方法

○保管場所は直射日光に当たらない風通しの良い涼しい場所を選んでください。
○夏の車中など高温になる場所に本製品を置かないでください。熱による変形や破損する可能性があります。

■ 廃棄方法

○廃棄方法はお住まいの自治体の収集方法に従ってください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。
製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。
なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

○本製品の誤った使用方法によるもの
○間違ったお手入れ、保管方法、経年変化による素材劣化
○乱暴な取り扱いによるもの
○その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ 仕様・サイズ

【品　番】	【品　名】	【サイズ】	【素　材】
#2351129	ホライゾンパドル カーボン	160cm～205cm	カーボンファイバー強化樹脂（シャフト/ブレード）
#2351130	ホライゾンパドル グラス	160cm～205cm	グラスファイバー強化樹脂（シャフト）、ポリプロピレン（ブレード）
#2351131	ホライゾンパドル アルミ	160cm～205cm	アルミニウム合金（シャフト）、ポリプロピレン（ブレード）
#2351132	ホライゾンパドル アルミ Kid's	120cm～160cm	アルミニウム合金（シャフト）、ポリプロピレン（ブレード）

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont·bell

User's Manual

Horizon Paddle Series

Horizon Paddle Series

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product. If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Note for parents/guardians

- When children use this product, parents or guardians should read this user's manual thoroughly and instruct the children on the correct usage of this product.
- NEVER allow children to use this product unless they are capable of operating it correctly. Improper use may cause injury or accidents.

■ Description

Specifically designed for stand up paddleboarding (SUP), featuring a length-adjustable shaft.

■ Components

*Illustrated is Horizon Aluminum Paddle.



■ Safety Warnings **Please read carefully.**

⚠ Danger! **Under certain conditions, use of this product can result in major injury or death.**

- ○Stand up paddleboarding is inherently dangerous and may cause injury or death to the user or to others nearby. Users of this product or any related products must acknowledge and accept the risks of injury or fatal accidents. To help prevent accidents, read the user's manual carefully before using this product and follow the instructions.
- ○Due to the characteristics of this product, it is not suitable for intense use that may place excessive loads on the product.
- ○Be aware of tidal changes and strong currents along coastlines. When paddling on a lake, river, or in coastal waters, sudden weather changes may cause strong wind gusts on the water. This product relies solely on human power. Use it safely without exceeding your paddling ability.

⚠ WARNING! **Under certain conditions, use of this product can result in injury, death, or property damage.**

- ○This product is designed for stand up paddleboarding. Do NOT use for any other purposes.
- ○Be aware of your surroundings to prevent property damage and injury to others.
- ○Prior to use, understand how to use the product and practice using it in a safe place. May result in injury or damage if not familiar with proper use.
- ○Do NOT alter or modify this product in any way. May cause injury, accidents, or damage.

⚠ CAUTION! **Under certain conditions, use of this product can result in injury or property damage.**

- ○Prior to use, parents/guardians shall read the user's manual thoroughly and educate the child. Make sure that the child understands the usage, and do NOT allow the child to use it unattended.
- ○This product is made of lightweight, durable material. However, it may be damaged if used in shallow water or in areas where it could strike rocks.
- ○Extended exposure to sunlight may cause discoloration or deterioration due to ultraviolet rays.
- ○Exposure to high water pressure or prolonged submersion may allow water to enter the shaft, reducing the buoyancy of this product.

■ Prior to use, inspect this product for:

Stop using immediately if you notice any irregularities.

- ☐ **Cracks, damage and other signs of wear and tear.**
- ☐ **Proper function of the length adjuster clamp.**

■ Directions

○Assembling the paddle and adjusting the length

Opening and closing the lever on the length adjuster clamp allows adjustment of the paddle length. The optimal paddle length varies depending on the intended use. As a general guideline, add approximately 15–25 cm to the user’ s height. Ensure that the front of the grip and the front of the blade are aligned in the same direction when adjusting the length.





*The Horizon Carbon Paddle and Horizon Fiberglass Paddle feature a shaft groove that automatically aligns the grip and blade angles.
*Hold the paddle with the concave side of the grip facing the direction of travel.
*Illustrated is Horizon Aluminum Paddle.



*A loose clamp lever may cause the upper shaft to come off. If the lever is loose, turn it clockwise as shown in the figure above to tighten the screw, then close the lever. Be careful not to overtighten, as this may damage the clamp.

⚠ CAUTION!

Do NOT extend the shaft past the "STOP" marking. Extending it beyond this point may apply excessive force to the joint during use, resulting in damage (see right figure).

■ Care

Improper care and storage can shorten the lifespan of this product.
Follow the recommendations below to extend the lifespan of your product.

○After use, clean off any dirt thoroughly. Remove the upper shaft, rinse the entire paddle with fresh water, and allow it to dry.
○If used in seawater and left assembled for an extended period, salt may crystallize and cause the joints to become stiff. After use in the sea, remove the upper shaft and rinse the entire paddle thoroughly with fresh water to remove any salt.

■ Storage

○Store in a well-ventilated, cool, dry place away from direct sunlight.
○Do NOT expose this product to temperature extremes, such as in a car in summer. May cause deformation and damage.

■ Disposal

○Follow local rules and regulations for proper disposal.

■ Warranty

Montbell’s warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell’s discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specifications

Style#	Name	Size	Material
#2351129	Horizon Carbon paddle	160cm～205cm	Carbon fiber reinforced resin (shaft/blade)
#2351130	Horizon Fiberglass paddle	160cm～205cm	Fiberglass reinforced resin (shaft), polypropylene (blade)
#2351131	Horizon Aluminum paddle	160cm～205cm	Aluminum alloy (shaft), polypropylene (blade)
#2351132	Horizon Aluminum paddle kid's	120cm～160cm	Aluminum alloy (shaft), polypropylene (blade)

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.
2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN
https://www.montbell.com/