

# ウィーリーバッグ用 キャスター 2個入り

## Replacement Caster For Wheely Bag(2pcs)

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用の前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。


### ■ 特長

ウィーリーバッグシリーズ専用の交換用キャスター（車輪）です。

### ■ 各部の名称

#### ○交換するもの

キャスター 2個



#### ○ご用意していただく工具

本製品に付属していません。お客様でご用意ください。

10mmスパナ



六角レンチ



プラスドライバー




※図1の場合




### ■ 交換方法

ウィーリーバッグ本体の形状によってキャスターの交換方法が異なりますのでご注意ください。


#### ○キャスター周辺の形状が〈図1〉の場合




- ①バッグ本体内側のジッパーを開けます。
- ②六角レンチ、スパナを使用してバッグ内側のナットとバッグ外側のボルト3箇所を外します（図A）。
- ③バッグ内側の取り付けネジをドライバーを使用して外し、バッグ外側のキャスタークーパーをバッグ本体から外します（図B）。
- ④六角レンチ、スパナを使用してキャスタークーパーの車軸ボルト、ナットを外し古いキャスターを取り除き、新しいキャスターと交換します（図C）。
- ⑤上記と逆の順序で各ボルト、ワッシャー、ナット、ネジを取り付けて工具で締めます。
- ⑥バッグ本体内側のジッパーを締めます。
- ⑦ボルト類に緩みがないか確認してから使用してください。




## ○キャスター周辺の形状が〈図2〉の場合



(图2)



(图D)



(图E)

- ①バッグ本体内側のジッパーを開けます。
- ②六角レンチ、スパナを使用してバッグ内部のナットとバッグ外側のボルトを外します(図D)。
- ③古いキャスター(車輪)を取り除き、新しいキャスターと交換します。
- ④ボルト、各ワッシャー、ナットを順に取り付けて工具で締めます(図E)。その際、ワッシャー大の順番を間違えないようにご注意ください。
- ⑤バッグ本体内側のジッパーを締めます。
- ⑥ボルト類に緩みがないか確認してから使用してください。

## ■ 廃棄方法

○廃棄方法はお住まいの自治体の収集方法に従ってください。

## ■ 仕様・サイズ

品 番：7051205

品 名：ウイーリーバッグ用 キャスター 2個入り

対 応：ウイーリーバッグ 40、ウイーリーバッグ 60、ウイーリーダッフル 90

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

# mont·bell

## User's Manual

# Replacement Caster For Wheely Bag(2pcs)

## Replacement Caster For Wheely Bag(2pcs)

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.


### ■ Description

Replacement caster (wheel) set designed for the Wheely Bag series.

### ■ Components

#### ○ Replacement parts

2 casters



#### ○ Tools needed

Tools are NOT included. Please prepare them yourself.

10mm spanner

Allen wrench

Screwdriver




In the case of Fig. 1

### ■ Replacing the caster

The replacement procedure varies depending on the shape of the Wheely Bag. Please check your bag type before proceeding.


#### ○ When the caster is fixed as shown in Fig. 1

(Fig. 1)




- ① Open the zipper on the inside of the bag.
- ② Remove the nut from the inside of the bag and the three bolts from the outside using an Allen wrench and a spanner (see Fig. A).
- ③ Unscrew the mounting screw on the inside of the bag using a screwdriver, then detach the caster cover from the bag body (see Fig. B).
- ④ Remove the axle bolt and nut from the caster cover using an Allen wrench and a spanner. Then, replace the old caster with a new one (see Fig. C).
- ⑤ Install and tighten each bolt, washer, nut, and screw by following the above procedure in reverse order.
- ⑥ Close the zipper on the inside of the bag.
- ⑦ Make sure that all parts are securely tightened before use.


(Fig. A)






(Fig. B)



(Fig. C)



## ○When the caster is fixed as shown in Fig. 2



- ① Open the zipper on the inside of the bag.
- ② Remove the nut from the inside of the bag and the bolt from the outside using an Allen wrench and a spanner (see Fig. D).
- ③ Replace the old caster with a new one.
- ④ Install the bolt, washers, and nut, then tighten with the tools (see Fig. E). Check that the large washers are installed in the correct order.
- ⑤ Close the zipper on the inside of the bag.
- ⑥ Make sure that all parts are securely tightened before use.

## ■ Disposal

○Please follow local regulations regarding waste disposal.

## ■ Specifications

Style# : 7051205  
Name : Replacement Caster For Wheely Bag (2pcs)  
Compatible product : Wheely Bag 40 · Wheely Bag 60 · Wheely Duffle Bag 90

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

**mont-bell Co.,Ltd.**

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN  
<https://www.montbell.com/>

44-5670-2411