

# mont·bell

## 取扱説明書

# アルパインサーモボトル 交換用アクティブリッド

### Alpine Thermo Bottle Active Lid

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長

本製品は、アルパインサーモボトルを直飲みできるボトルに変更するためのふたのセットです。片手でワンタッチ開閉ができ、素早く手軽に水分補給が可能です(コップセットと比較して保温性能は低下します)。ご使用にあたってボトル本体に付属する取扱説明書も併せてお読みください。

## ■ 各部の名称




**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

- 熱い飲み物を飲む際は本体を急に傾けずゆっくり飲んでください。やけどの恐れがあります。
- 火のそばに置かないでください。破損の恐れがあります。
- 初めてご使用になる前に、食器用洗剤を含ませた柔らかいスポンジなどでよく洗浄してください。
- ロックバーは確実に閉め、漏れがないことを確認してください。
- 万一の漏れを避けるため、製品は縦向きにして持ち運びください。
- 長期間使用されるとパッキンが消耗し、飲み物が漏れることがあります。


## ■ 使用方法

### ○ 飲み物を入れる

飲み物の量は、図の位置までにしてください。入れすぎた状態でアクティブリッドを閉めると、飲み物が溢れ出る恐れがあります。



### ○ 飲み物を飲むとき



ロックバーを上押しして解除します。

開閉ボタンを押して蓋を跳ね上げます。



携行する際は必ずロックしてください。


## ■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考してください。


- ご使用後は、すぐにきれいに洗い、十分に乾燥させてください。
- アクティブリッドのみ食器洗浄機が使用できます。ボトル本体(別売)は食器洗浄機が使用できません。
- お手入れは、ぬるま湯で薄めた食器用中性洗剤を使用してください。
- 煮沸はしないでください。熱により部品が変形し、飲み物が漏れる恐れがあります。

## ○ 分解・組立て


洗浄や乾燥の際は分解が可能です。



## ・飲み口の取り外し方法




## ・飲み口の取り付け方法



- ① アクティブリッド本体の内側に飲み口をななめに差し入れます。
- ② 飲み口の手前側のツメを本体にのせます。
- ③ 飲み口の奥側をカチッと音が出るまで押し上げます。

## ・飲み口パッキンの装着方法

飲み口に装着されているパッキンの形状は上下で異なります。取り外したパッキンを再装着する際は上下の向きに注意してください(右図参照)。取り付け後はパッキンのずれやねじれ、水漏れが無いことを必ず確認してください。



パッキンなどの消耗品の交換については、販売店もしくは弊社窓口までお問い合わせください。

## ■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理をさせていただきます。

## ■ 仕様・サイズ

品番	品名	材質
#1124887	アルパインサーモボトル 交換用アクティブリッド	ポリプロピレン、ABS(ロックバー、ボタン) シリコンゴム(パッキン)

○ 対応ボトル：アルパインサーモボトルシリーズの0.35Lと0.5Lのみ取り付け可能です。シリーズの0.75Lと0.9Lには対応しません。

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

# Alpine Thermo Bottle Active Lid

## Alpine Thermo Bottle Active Lid


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

### Description

A replacement lid that allows you to drink directly from the Alpine Thermo Bottle Series. Features a button that allows you to quickly open the cap with push of a button (use of this lid slightly affects the bottle's insulating properties). Before using, make sure to review your Alpine Thermo Bottle's User's Manual.

### Components



**CAUTION!** Under certain conditions, use of this product can result in injury or property damage.

- Tilt the bottle slowly and drink slowly in order to avoid burning your mouth with hot contents.
- Keep away from fire.
- Before using for the first time, wash the bottle with a soft sponge and soap.
- Close the lock bar completely and check for leaks.
- Store the bottle upright to prevent accidental leakage.
- The seal will deteriorate after extended use, which can lead to leaking.


### Directions

#### Filling the bottle

Fill the bottle below the marked line. If overfilled, the contents can spill over when putting on the active lid.



#### How to use




### Care


- After use, wash and air dry thoroughly.
- Active lid is dishwasher-safe. Bottle body is NOT dishwasher-safe.
- When washing, use lukewarm water and a mild soap.
- Do NOT sterilize by boiling. High temperatures can cause the parts to warp, which can possibly lead to leaks.

### Active lid disassembly and assembly

For cleaning and drying, it is possible to disassemble the active lid.




#### Disassembling the active lid



Push down on the far side of the drinking spout.

#### Assembling the active lid




① Insert the drinking spout into the active lid at an angle.

② Make sure the tab on the drinking spout is seated on the active lid.

③ Push on the back of the drinking spout until it clicks into place on the active lid.

#### Attaching the drinking spout's rubber seal

The drinking spout's rubber seal has a right-side up. Make sure to put the rubber seal back on as shown here in the figure. After attaching the rubber seal, make sure the seal is fully attached to the drinking spout, that the seal isn't twisted or that liquid does not leak from the bottle.



For replacement of components such as rubber seal, contact the store of original purchase or Montbell Customer Service.

### Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

### Specifications

Style#	Name	Material
#1124887	Alpine Thermo Bottle Active Lid	Polypropylene, ABS( Lock bar, Button ) Silicone (Seal)

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

www.montbell.com