mont·bell

共通取扱説明書

アルパイングーグル
イージーチェンジ シリーズ

Alpine Goggles Easy Change Series


この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用の前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品は防曇性能と光学性能に優れたレンズを使用し、登山やスキー・スノーボードに適したゴーグルです。マグネット式により、簡単に状況に合わせたレンズ（別売）に交換することができます。

■ 各部の名称 ※イラストはアルパイングーグル イージーチェンジHDです。



■ 安全上の注意 必ずお読みください

⚠ 警告 場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

◯本製品を、登山、スキー及びスノーボード以外に使用しないでください。

◯本製品は太陽光の紫外線などをカットし、雪や風などを防ぐように作られています。強い衝撃などから眼を保護するものではありません。

◯ご使用前に、必ず点検してください。老朽化や、レンズ、フレームに損傷がある場合はご使用にならないでください。
※特にレンズの傷は昼間気にならなくても、ナイターでの使用時に著しく視界の妨げになることがあります。

◯ご自身による修理・改造は、安全上の問題が生じますのでおやめください。

◯本製品は、安全に十分配慮して設計されていますが、過度の衝撃が加わるとレンズが破損し、顔や眼に重大な傷害をおよぼす場合がありますので、十分にご注意ください。

◯本製品は強力な磁石を使用しているため、クレジットカードなどの磁気媒体や磁気に弱い機器から遠ざけてください。不具合や故障などの恐れがあります。また、ペースメーカーや植込み型除細動器の動作に影響する可能性があります。装着している方は医師に相談してください。

◯本製品の磁石は外れにくい構造となっていますが、万が一外れた場合は、子どもの手の届かない場所に保管してください。誤って飲み込んだ場合は、重篤な事故につながる恐れがあるため、直ちに医師に相談してください。

⚠ 注意 人が傷害を負ったり物的損害の発生が想定される内容です。

◯使用中に肌に異常が現れた場合はただちに使用を中止し、医師に相談してください。

◯暖房器具の近くや、乾燥室など温度の高い場所（50℃以上）に本製品を置かないでください。
※50℃以上になると、レンズやフレームが変質・変形する可能性があります。

◯温度や湿度が高い場所に本製品を置くと、他の衣類やヘルメットに色が移る場合があります。

◯ベンチレーター（換気口）に付着した雪や水滴などは、こまめに取り除いてください。そのまま放置すると通気を妨げたり、水滴が本製品内に入り込み、レンズの曇りの原因になります。

◯レンズ表面に残った水分や雪・氷は、ゴーグルをよく振って取り除き、必要であれば柔らかい布などで押し当てるようにして、水分を吸い取ってください。

◯寒冷地でレンズに氷が付着したら、そのまま氷をこすらず、一度溶かしてから柔らかい布などで軽く押し当てるようにして、水分を吸い取ってください。氷をそのまま拭くと、レンズに傷が入りやすくなります。

◯レンズに直接手を触れないようにしてください。

◯レンズ内面側に親水性の曇り止め加工を施しています。曇り止め加工は水分を吸収しレンズの曇りを防ぎますが、水分を吸収したレンズは、通常時のレンズに比べ傷が付きやすくなります。水分を吸収している場合は、レンズを拭かないでください。汚れや傷が付いた部分は、曇り止め機能が低下することがあります。

◯本製品の使用中にレンズの曇り止め効果が低下し、曇りはじめることがありますが、これはレンズの水分吸収量が飽和したためで、レンズに含んでいる水分を常温（室温）で十分乾燥させれば、再び機能は回復します。

◯レンズに曇り止め液・撥水液・クリーナーなどは塗らないでください。曇り止め効果が損なわれることがあります。市販されている曇り止め液の中には、レンズを傷めるものもあります。

◯ミラーコートレンズは、細かなキズが入ることにより、ミラーコートが剥がれることがあります。グローブや硬いものなどで、レンズを擦らないでください。

◯ミラーコートレンズ表面にくもり止め液を塗らないでください。ミラーコーティングが剥がれる恐れがあります。

◯シンナー等の有機系溶剤は変形・変色の原因となりますので使用しないでください。また、アルコールでお手入れをする場合はレンズ内側以外の箇所に使用しないでください。

◯転倒など強い衝撃を受けるとレンズが外れ、紛失や破損する恐れがあります。

◯使用前にレンズがフレームに隙間なく固定されていることを確認してください。フレームからレンズが浮いている場合は外れやすくなるため、隙間に雪やゴミが付着してる際は取り除き、密着するように押し込んで固定してください。

■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。
異常が見られた場合は使用しないでください。

□レンズやフレームに傷などがないか　　**□ベルトは正しく調節できているか**


■ 使用方法

◯本製品を装着し、ベルトを調節し、顔に合わせてください。

◯レンズ交換方法

レンズ交換はゴーグルを顔から外し、ゆっくり確実に行ってください。無理に行うとフレームやレンズを破損する原因となります。


■取り外し方



❶図のように本体フレームと、レンズフレームをしっかり持ちます。指紋や皮脂がレンズに付かないようにしてください。


❷マグネットの固定が強いため、両親指にやや力をかけて引き離してください。一度に大きく外そうとせず、片側の固定を外してから順番に周囲の固定部を外します。無理なひねりや急な引っ張りは避けてください。

■取り付け方



❶本体フレームと、レンズフレームの向きを揃えます。レンズを本体フレームの上側から近づけ、ノーズ部分を合わせます。

❷側面に4か所あるツメを図のようにしっかりと密着するように押し込みます。



■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。
使用後や保管時は以下の点を参考にしてください。

◯レンズ外側に付いた水あか、指紋、手あかなどの汚れは、付属のレンズクリーナー兼収納袋で優しく拭き取ってください。

◯細かな砂や泥などの汚れは、フレームからレンズを取外し、流水でレンズ表面を指でなでるように洗い流してください。その後、レンズをよく振って水分を取り除き、柔らかい布などで押し当てるようにして水分を吸い取り、自然乾燥させてください。

◯レンズに曇り止め液やはっ水液などを塗らないでください。本製品は優れた防曇（曇り止め）機能を施していますが、市販されている曇り止め液やクリーナーはこの防曇性能を低下させる恐れがあります。

◯レンズの内側が汚れた場合は、アルコールを含ませた柔らかい布等で汚れをぬぐい取ってください。
※レンズの内側以外の箇所は、変形・変色の原因となりますのでアルコールは使用せず、中性洗剤で洗ってください。

◯レンズが割れたり傷がついた場合は、新しいレンズ（別売）を交換してください。

■ 保管方法

◯火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。

◯保管場所は高温多湿を避け、直射日光の当たらない風通しの良い場所を選んでください。

◯濡れた状態で放置・保管しますと、ベルトやフレーム、レンズの材質を傷めたり、レンズが曇りやすくなることがあります。濡れたゴーグルは水分をよく取り、十分に自然乾燥させてください。

◯長時間外圧を加えると変形することがあります。また、二重構造のレンズ剥がれの原因にもなり、内・外レンズの間に曇りが発生する原因になります。保管中や輸送中に硬いもの（金属品、バックル、ジッパー、角のあるプラスチック等）がレンズ面に触れないようご注意ください。

■ 廃棄方法

◯廃棄方法はお住まいの自治体の収集方法に従ってください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。
製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。
なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

◯本製品の誤った使用方法によるもの　◯間違ったお手入れ、保管方法、経年変化による素材劣化
◯乱暴な取り扱いによるもの　◯その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理をさせていただきます。

■ 仕様

品番	品名	素材
1109263	アルパイングーグル イージーチェンジ HD	レンズ：（外レンズ）ポリカーボネート （内レンズ）トリアセテート （レンズフレーム）ナイロン/ネオジム磁石 フレーム：ポリウレタン クッション、ベンチレーション：ウレタン・フォーム
1109264	アルパイングーグル イージーチェンジ PL	
1109265	アルパイングーグル イージーチェンジ	

●付属品　収納袋（レンズ拭き兼用）
※レンズの可視光線透過率は箱の外に記載しています。

■ オプション（別売）

本製品は下記の別売のオプションを利用することができます。
● 交換レンズ　HD（高精細）、PL（偏光）、ノーマルレンズ

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont·bell

User's Manual

Alpine Goggles Easy Change Series

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.


If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

■ Description

Utilizes a lens with anti-fogging and superior optical performance. Well suited for mountaineering, skiing and snowboarding. The magnetic lens system makes it easy to swap to optional lenses (sold separately) to match changing conditions.

■ Components

*Illustration shows Alpine Goggles Easy Change HD.



■ Safety Warnings

Please read carefully.

⚠ WARNING! **Under certain conditions, use of this product can result in injury, death, or property damage.**

◯Do NOT use this product for any purposes other than mountaineering, skiing, or snowboarding.

◯This product is designed to reduce the harmful effects of the sun's ultraviolet light and protect the eyes from snow and wind. This product does NOT protect the eyes from strong impacts.

◯Prior to use, check the product's condition and stop using immediately if you notice any damage or irregularities.

*While lens scratches may not be noticeable during the day, they can significantly impair visibility at night.

◯NEVER modify or alter this product. Modifications and alterations may damage the product and impair functionality.

◯Although this product is designed with safety in mind, excessive impact may break the lens and cause serious injury to the face or eyes. Handle with care.

◯This product uses a strong magnet. Keep it away from credit cards, other magnetic media, and magnet-sensitive devices. May cause malfunctions or damage. The magnet may also interfere with pacemakers and implantable cardioverter-defibrillators. Users of such equipment should consult a physician.

◯Although the magnets in this product are securely attached, if they accidentally detach, keep them out of reach of children. If swallowed, consult a physician immediately. May lead to serious injury.

⚠ CAUTION! **Under certain conditions, use of this product can result in injury or property damage.**

◯If you experience any skin abnormalities during use, stop using the product immediately and consult a physician.

◯Do NOT place near heat sources or in rooms that exceed 50°C.

*At temperatures of 50°C or higher, the lenses or frame may deteriorate or deform.

◯Do NOT store this product in extreme temperature and humid conditions. May cause color transfer.

◯Regularly clear snow and water droplets from the vent. Leaving them can obstruct ventilation and cause water to seep inside, leading to lens fogging.

◯Do NOT leave moisture, snow, or ice on the lens. Make sure to shake it off or dab with a soft cloth.

◯If water freezes on the lens, do NOT try to rub off the ice. Instead, give the ice time to thaw and use a soft cloth to wipe away. Attempting to rub ice off the lens can cause scratches.

◯Do NOT handle lens with bare hands.

◯The inner lens is coated with a hydrophilic anti-fog coating. The coating prevents fogging by absorbing moisture, but in doing so, it becomes more susceptible to scratches than when dry. If the lens is wet, do NOT wipe. Smudges and scratches can negatively affect the anti-fogging performance.

◯The lens' anti-fog performance may decrease, and the lens may begin to fog when the coating becomes saturated. Allowing the lens to dry thoroughly at room temperature will restore its anti-fog performance.

◯Do NOT apply anti-fog, water-repellent, or cleaning agents to the lens, as these may impair the performance of the original anti-fog treatment. Some commercially available anti-fog solutions may damage the lens.

◯Small scratches on mirrored lens can cause the mirror coating to peel. Do NOT rub with gloves or rigid objects.

◯Do NOT spray mirrored lens with anti-fog solutions. May cause the mirror coating to peel.

◯Do NOT clean with thinners or other organic solvents. May result in deformation or discoloration. When cleaning with alcohol, do NOT apply to areas other than the inside of the lens.

◯Strong impacts such as falling may cause the lens to detach, leading to loss or damage.

◯Prior to use, ensure the lens is securely fitted to the frame with no gaps. If the lens is loose or lifting from the frame, it may detach easily. Remove any snow or debris from the gaps, then push the lens in until it is securely fitted.

■ Pre-Use Inspection

Prior to every use, inspect this product for the following.
Stop using immediately if you notice any irregularities.

□Damage to lens and frame **□Strap is adjusted correctly**


■ Directions

◯Put on the product and adjust the strap to fit your face.

◯Changing the lens

Always remove the goggles from your face before changing the lens, and handle the procedure with care. Applying excessive force may cause damage to the frame or lenses.


■Detaching



❶Hold the main frame and lens frame firmly as shown in the figure. Avoid getting fingerprints or skin oils on the lens.

❷The frame and lens are securely attached by the magnet. Apply firm pressure with both thumbs to pull them apart. Do not attempt to detach it all at once. Detach one side first, then proceed around the frame in order. Avoid excessive twisting or sudden pulling.


■Attaching



❶Align the main frame and the lens frame. Bring the lens toward the main frame from above, and align the nose sections.

❷Push the four tabs on the side firmly into place as shown in the figure.

⚠ **CAUTION** Ensure there are no gaps or spaces between the lens frame and the main frame.



■ Care

Improper care and storage can shorten the lifespan of this product.
Follow the recommendations below to extend the lifespan of your product.

◯Gently wipe away water stains, fingerprints, and hand oils on the outer lens using the included lens wipe/stuff sack.

◯To remove fine sand or mud, detach the lens from the main frame and rinse its surface by gently rubbing with your fingers under running water. Then shake the lens thoroughly to remove excess water, gently press a soft cloth against it to absorb any remaining moisture, and allow it to air-dry.

◯Do NOT apply anti-fog agents, water repellents, or similar products to the lens. Commercially available anti-fog agents or cleaners may reduce the effectiveness of this product's high-performance anti-fog coating.

◯To clean the inner lens, wipe with a soft cloth moistened with alcohol.
*Do NOT use alcohol on any part other than the inner lens, as it may cause deformation or discoloration. Instead, clean those parts with a mild detergent.

◯If the lens is cracked or scratched, replace it with a new lens (sold separately).

■ Storage

◯Do NOT place the product in a place where it will be exposed to high temperatures such as near a fire or heater. May cause deformation or damage.

◯Store in a well-ventilated place away from high temperatures and humidity, and out of direct sunlight.

◯Leaving or storing the product while wet may deteriorate the strap, frame, or lens, and can cause the lens to fog easily. After use, wipe off moisture and allow them to air dry completely.

◯Prolonged external pressure may cause deformation. May also cause the layers of the double-layer lens to separate, resulting in fogging between the inner and outer lenses. Do not allow hard objects (metals, buckles, zippers, sharp-edged plastic, etc.) to come into contact with the lens surface during storage or transport.

■ Disposal

◯Follow local rules and regulations for proper disposal.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specification

Style#	Name	Material
1109263	Alpine Goggles Easy Change HD	Lens : (outer lens) polycarbonate (inner lens) triacetate (lens frame) nylon /neodymium magnet Frame : polyurethane Cushioning, vent : urethane foam
1109264	Alpine Goggles Easy Change PL	
1109265	Alpine Goggles Easy Change	

●Stuff sack included (Doubles as a lens wipe)

*Light transmission is printed on box.

■ Accessories (sold separately)

This product can be used with the following accessories (sold separately).

● Replacement Lens (Normal), HD (High-definition), PL (Polarized)

All product specifications and design are subject to change without prior notice.
Actual product specifications may vary.

mont·bell Co.,Ltd.
2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN
https://www.montbell.com/

44-6782-2610