

mont·bell

共通取扱説明書

フットウエア

Footwear

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 各部の名称



※使用されている素材は、各製品の品質表示をご覧ください。

※イラストはイメージです。

■ 安全上の注意 必ずお読みください



警告 場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に機能が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。
- フックを使用している登山靴は、足首内側のフックが反対の靴に引っ掛かり、転倒やケガの恐れがあります。靴を履く際は、必ず靴ひもを一番上まで締めてください。痛みなどの理由で靴ひもを上まで締めずに歩く場合や、下山中、稜線歩きの際は、特に慎重な足運びをお願いします。また靴ひもが長すぎると結び目のループが大きくなり、フックに引っ掛かりやすくなります。その場合は、二重結びや靴ひものサイズ交換等に対応してください。

1

- BOA®フィットシステムを採用したシューズで傷んだままのワイヤーレースの使用を続けると、ごくまれにワイヤーレースが破損する（切れる）場合があります。ワイヤーレースの切断面は鋭利になりますので取り扱いに注意してください。



注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- ソールの貼りつけに使用している接着剤は、靴の使用の有無にかかわらず経年劣化により剥離が起こる可能性があります。使用後のお手入れや保管方法は本説明書に従って行ってください。
- 経年劣化や接着剥離は使用中に突発的に起こる可能性が高く、事故の原因にもなる可能性があります。ご使用前は靴本体やアウトソール（靴底）、ミッドソール（中底）、フック、D環等に異常がないことを点検してください。
- アウトソール（靴底）は屈曲を繰り返してひび割れ等の異常がないか確認してください。異常が見受けられた場合は直ちに使用をやめ、販売店もしくは弊社カスタマー・サービスまでお問い合わせください。
- 新しい靴でフィールドに出かける際は必ず十分に慣らし履きを行ってください。靴擦れなどのケガの恐れがあります。
- 油がひいてある場所で使用しないでください。転倒やケガの恐れがあります。
- 靴ひもは傷みにより、切れることがあります。フィールドに出かける際は必ず予備の靴ひもをお持ちください。
- BOA®フィットシステムのレースは傷みにより、切れることがあります。フィールドに出かける際は、万一来予備のレース、ドライバー（またはツール）、付属のBOA®フィットシステム用の取扱説明書をご持参ください。

■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。
異常が見られた場合は使用しないでください。

- | | |
|--|--|
| ☐ ソールのはがれがないか | ☐ アウトソール（靴底）が擦り減っていないか |
| ☐ 縫い目のほつれや留め具の脱落がないか | ☐ 靴ひもが傷んでいないか |
| ☐ アッパー（甲皮）の屈曲部にひび割れなどがないか | ☐ アウトソール（靴底）が屈曲を繰り返してひび割れ等の異常がないか |

■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。
使用後や保管時は以下の点を参考にしてください。

靴のお手入れ方法は使用素材によって異なります。素材に適した方法でお手入れしてください。汚れを放置すると経年劣化が進み、ソールのはがれの原因につながります。


※使用されている素材は各製品の品質表示をご覧ください。

○ ご使用後のお手入れ

① 汚れ落とし

1) アウトソール（靴底）

水洗いしてください。頑固な汚れはブラシを、詰まった石にはマイナスドライバーを使用すると簡単に取り除くことができます。
※マイナスドライバーでソールや手を傷つけないようにご注意ください。




▲詰まった石を取り除く

2) アッパー（甲皮）部分

靴ひもを靴から外します。靴用ブラシ等（ヌバックやスエードの場合は専用ブラシ）を用いて汚れを落とし、頑固な汚れは水洗いしてください。市販の靴専用洗剤以外のご使用は、皮革パーツを傷める恐れがあります。

・靴ひも

外した靴ひもをネットに入れ、洗濯機を使用すると手軽に洗えます。




▲靴用ブラシで汚れを落とす

2

3) フットベッド(中敷き)・靴内部

フットベッド(中敷き)は使用するたびに取り出し、しっかり乾燥させてください。フットベッドを取り出すことで靴内部も乾かしやすくなります。フットベッドの汚れがひどい時は靴用洗剤とブラシで洗ってください。

靴内部のライニングが革であれば、汚れを拭き取って落とし、ファブリック(合成繊維)であれば、ブラッシングで汚れをかき出してください。




▲靴内部についた泥を落とす

2 乾燥

直射日光を避けて、風通しの良いところで2~3日かけて乾燥させてください。靴内部に水分が残っている場合は、靴用の乾燥剤を靴の中に入れてください。

※濡れた状態で直射日光やヒーター等で急激に乾燥させないでください。皮革のヒビ割れや硬化の原因となります。また靴の接着部分にすきまができたリソール等のはがれにつながる恐れがあります。



3 はっ水

はっ水処理は、汚れを取り除き、乾燥を済ませた後に行ってください。汚れがついたままはっ水処理を行うと正しいはっ水効果が得られず、防水透湿性素材を使用している場合は性能を発揮できない恐れがあります。

■皮革製ブーツ

汚れを除去して乾燥させた後に市販の保革クリーム等を塗布します。続いてはっ水スプレーを施し、自然乾燥させます。スプレータイプの保革剤入りはっ水剤を使用すると、保革剤を塗る手間が省けます。

※素材を長持ちさせるために効果的な保革クリームを併せて使用されることをおすすめします。

ただし、風合いが変わるため、目立たないところで試してから全体に塗り込んでください。

■ファブリック(合成繊維)、合成皮革製ブーツ

汚れを除去して乾燥させた後にはっ水スプレーを塗布します。

保革クリームは使用しないでください。

⚠ 注意

はっ水スプレーを使用する際は、必ず風通しの良い野外で行ってください。ご使用になるはっ水スプレー・保革クリームなどについては、それらの製品に付属の「取扱説明書」「注意書き」をよくお読みいただきご使用ください。



■ 保管方法

- 風通しがよく、湿度が高くない場所で、直射日光を避けて保管してください。
- 火のそばや暖房器具のそばなどの高温になるところに置かないでください。変形や損傷の原因になります。
- 購入時の靴箱や収納袋に入れて保管しないでください。湿気で靴の接着剤が劣化したり、カビの原因になります。
- 直射日光のあたる庭の物置や車のトランクなど高温になる場所に保管しないでください。変形や損傷の原因になります。

■ 廃棄方法

- 廃棄方法はお客様の自治体の収集方法に従ってください。

■ アフターサービス

お問い合わせいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お問い合わせいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理をさせていただきます。

アウトソール(靴底)の交換

モンベルではアウトソールの交換修理を有償にて行っています。アウトソール(靴底)の磨耗は、スムーズな歩行を妨げます。「滑りやすくなった」と感じたり、かかとやつま先部の減りが目立つようなら早めに交換をしてください。

また、ミッドソール(中底)や靴本体との接合部の損傷にも注意し、異常が見られた場合は直ちに使用をやめ、販売店もしくは弊社カスタマー・サービスにご相談ください。なお、一部の製品はアウトソール(靴底)の交換に対応していないものもございます。モンベルカタログやホームページをご覧ください。か、販売店もしくはモンベルカスタマー・サービスにご相談ください。

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont-bell

User's Manual


Footwear

Footwear

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Components



※Check the product's specifications for material information.

※Illustration. Actual product may vary.

Safety Warnings! Please read carefully.

WARNINGS! Under certain conditions, use of this product can result in injury, death, or property damage.

- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair function.
- Please follow recommended care and storage instructions. Improper care and storage can lead to decrease in performance.
- Prior to use, check the shoe's condition and stop using immediately if you notice any damage or irregularities.
- Make sure lacing the boots all the way up. Otherwise, a free hook may catch on the hook of the opposite boot, resulting in a fall or injury. When walking without lacing them all the way up, due to blisters or any other reason, pay special attention to your steps. A bigger lace loop is likely to snag in the hook of the other boot. In order to avoid an accident, try making loops smaller by tying a double knot or replacing the laces with shorter ones.
- For shoes utilizing the BOA® Fit System, in extremely rare cases, damaged laces can snap, creating sharp ends. When handling snapped laces be careful of cutting yourself.



CAUTION!

Under certain conditions, use of this product can result in injury or property damage.

- The glue that is used to attach the sole to the shoe can degrade over time causing the sole to peel off of the shoe, even if the shoe is never used. To help prevent this, please follow the care instructions in this manual.
- Accidents can occur while you are hiking or trekking due to glue degrading or aging. Prior to use inspect the outsole, midsole, hooks and D rings for damage or irregularities.
- When inspecting the outsole, look for cracks in the rubber that can result from the constant bending of the shoe. If you notice any damage or irregularities, stop using immediately and contact Montbell Customer Service or the original store of purchase.
- Before using new shoes, be sure that they are thoroughly broken in. New shoes that have not been broken in can cause foot pain and possibly lead to injury.
- Do NOT use on oiled surfaces. There is a possibility of slipping and causing injury.
- Prior to use, check the shoelaces for damage. Shoe laces that are damaged can sever during use.
- For shoes utilizing the BOA® Fit System, prior to use, check the shoelaces for damage. Shoe laces that are damaged can sever during use. When wearing these boots, we recommend bringing the driver, a spare set of laces and this manual.

Check before use ; Check the product's condition before each use and stop using immediately if you notice any irregularities.

- | | |
|--|---|
| ☐ The sole is not peeling away from the shoe. | ☐ The outsole has not become worn. |
| ☐ Damage to the stitching or missing shoelace hooks | ☐ Damage to the shoelaces |
| ☐ Tears in the upper from bending | ☐ Cracks in the outer sole from repeated bending |

Care Improper care and storage of your boots can shorten their lifespan. Follow the recommendations below to extend the lifespan of your boots.


Care instructions are different depending on the material of the shoe. Always following care instructions based on the shoe's material. Soiled shoes will degrade and age quicker and can lead to the sole peeling away from the shoe. ※Check the product's specifications for material information.

Care after use

1) Washing

1) Outsole

Wash with water. For heavy soiling or stains use a brush. For rocks lodged in the treads, carefully use a screwdriver to remove, taking care not to damage the shoes or injure your hand.




▲Removing a rock lodged in the shoe's tread

2) Upper

Remove the laces. To clean, use a shoe specific brush (for nubuck or suede shoes, use a brush suitable for leather) and for heavy soiling, wash with water. Only use shoe specific soaps. Ordinary soaps can damage the leather parts of a shoe.

- Laces can be placed in a laundry bag and washed in a washing machine.




▲Using a brush to remove soiling

3) Inside the shoe including footbed (insole)

After every use, remove the insole from the shoe and allow it to dry completely. This also allows the inside of the shoe to dry. If necessary, the insoles can be washed using a shoe specific cleaner and a brush.

If the inside of the shoe is leather, it can be wiped cleaned. If the lining is a synthetic material, it can be cleaned using a brush.




▲Dirt being removed from the inside of the shoe

2 Drying

Allow to dry for 2 to 3 days in a well ventilated, cool, dry place. If there is water in the shoe, insert a shoe drying insert into the shoe.

※Do not dry wet shoes in the sun or near a heater or dryer.

Drying too quickly can damage leather and cause cracking and stiffening. This can also damage the adhesive and cause the sole to peel away from the shoe.



3 Water Repellant

Apply water repellant after the shoes have been cleaned and allowed to dry. Applying water repellant while the shoe is soiled will not properly treat the shoes and can affect breathability of shoes with a waterproof/breathable membrane.

■Leather boots

Once clean and completely dry, first apply a leather conditioner. Next apply the water repellant and allow to dry completely. You can avoid the extra step of applying conditioner by using a water repellant spray that also contains leather conditioner.


※Although leather conditioner will help suede boots last longer, it will change the appearance of the material. Test by applying to an inconspicuous spot on the boot before applying to the entire boot.

■Fabric (synthetic fibers), Synthetic leather

Once clean and completely dry, apply the water repellant and allow to dry completely. Do NOT use leather conditioner.

⚠ **Apply water repellant spray in a well-ventilated place.**

Before using water repellent products and leather conditioners, be sure to read the directions.



■ Storage

- Store in a well ventilated, cool, dry place out of direct sunlight.
- To prevent deforming and damage, do NOT store near heat sources.
- Do NOT store in the box or bag at the time of purchase. Mold can grow and the product can start to prematurely deteriorate.
- Do NOT store in a car trunk or other area subject to high temperatures. May cause deforming and damage.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

Resoling services

Outsoles that have worn down can affect how you walk. If you notice that the treads aren't "gripping" well or if the toes or heels have become worn, it is generally time to replace the soles. If you notice the midsole has started to peel away from the shoe, stop using the shoes. Montbell provides sole replacement services at a reasonable rate, though there are some shoe models that can't be resoled. For additional information, please visit our website, contact Montbell Customer Service or the store where your shoes were originally purchased.

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN
<https://www.montbell.com/>

mont·bell

共通取扱説明書

アルパインクルーザー® 800 BOA® フィットシステム

Alpine Cruiser 800 (BOA® Fit System)

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。



※本説明書はBOA® フィットシステムの取扱説明書です。靴の取扱説明書は別紙を参照してください。

■ 特長

本製品は夏場の長期縦走やトレッキングなどに最適な全天候型のトレッキングブーツです。また、「BOA® フィットシステム」を使用し、ダイヤルを回すことで素早くフィット感の調節ができ、脱ぎ履きも容易に行えます。甲部分と足首部分の2カ所に独立したダイヤルを設けているので、細やかなフィット感の調節が可能です。

■ 各部の名称

※イラストは右足です。



■ 安全上の注意

必ずお読みください

警告 場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に機能が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。
- 傷んだままのレースの使用を続けるとごくまれにレースが破損する（切れる）場合があります。レースの切断面は鋭利になりますので取り扱いに注意してください。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。

- レースを交換する際は、本説明書を参考にして正しい手順で行ってください。誤った方法で行うとレースが破損し、転倒などの恐れがあります。
- レースがダイヤル部内で絡まりダイヤルが動かなくなった際は、新しいレースと交換してください。
※絡まったレースや動かなくなったダイヤルを無理に引くと破損する恐れがあります。



注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- 付属のツール以外の工具は使用しないでください。
- ご使用前にレースが傷んでいないかのチェックをしてください。
- フィールドへ行かれる際は、予備のレース、ツール、本説明書を持って行くことをお勧めします。

■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。
異常が見られた場合は使用しないでください。

- ☐ダイヤル部に亀裂などが無いか
- ☐レースが傷んでいないか

■ 使用方法

※イラストは左足です

○ レースのゆるめ方

- ① 上部ダイヤルをカチッと音がするまで上下2カ所のダイヤルを引き出します。
- ② 上部ダイヤルのレースはブーツのタンを前に引き出しゆるめます。下部ダイヤルのレースは、プルタブを引っ張りゆるめます。


○ レースの締め方

- ① 下部ダイヤルをカチッと音がするまで押し、ダイヤルを時計回りに回して締めます。
- ② 上部ダイヤルをカチッと音がするまで押し、ダイヤルを時計回りに回して締めます。

○ レースの交換方法

本製品の「BOA® フィットシステム」で使用しているレースは大変丈夫なステンレス製ワイヤーですが、消耗品のため使用頻度によっては破損する（切れる）場合があります。ご使用前にレースが傷んでいないかの確認をしてください（右図参照）。レースが破損した（切れた）場合は、下記の方法で交換してください。

レースが傷んでいる例



- 交換用レースを購入いただき、「ご自身での交換方法」に沿って、お客さまご自身での交換。
- 販売店もしくは弊社カスタマーサービスでの交換（シューズをお預かりのうえ有償）。
※付属のツール以外の工具は使用しないでください。
※レースの切断面は鋭利になっています。取り扱いにご注意ください。
※フィールドへ行かれる際は、予備のレースまたは靴ひも、ツール、本説明書を持って行かれることをお勧めします。

○ ご自身での交換方法


右の表を参考にして、“#1129384 BOA® フィットシステム 交換用レース0.81mm”を購入してください。

△本製品は上部用・下部用の2本のレースが必要です。



靴のサイズ	(cm)		
	22.0~24.5	25.0~27.5	28.0~29.0
上部ダイヤル用レースの長さ	40	45	50
下部ダイヤル用レースの長さ	75	80	85

⚠ レースの交換は片足ずつ行い、もう片方を参考にしながら行ってください。

- ① ツールをイラストの場所に差し込み、押し上げてダイヤルを取り外します。
- ② ツメを取り外します。取り外しにくい場合はツールを使用します。
- ③ スプールを取り出します。
- ④ スプール及び靴からレースを取り除きます。その後、逆の手順でツメを取り付けてください。





- ⑤ ダイヤルを押して「カチッ」という音が鳴るまでロックしてください。
- ⑥ ダイヤルの裏側にある矢印同士をあわせませす。
- ⑦ 新しいレースを下から順に靴のガイドに通します。






※レースはねじれないように通してください。
※レースが通りにくいときはレースを回しながら通してください。
※プルタブが付属している場合は忘れずにレースを通してください。

- ⑧ 差込口と反対側中央にある出口に向かって、レースを通します。
- ⑨ 片側のレースをつかみループをつくります。
- ⑩ ⑨でつくったループにレースの末端を通します。



※必要に応じてペンチ等を使用してください。


- ⑪ レースの先端を引っ張り、結び目がしっかりと締まっているか確認します。
- ⑫ レースの先端から結び目までの長さは4mm-7mm 以内におさめます。
- ⑬ レースを引っ張り、結び目がダイヤル内におさまるようにします。




⑨に戻り、もう片側も同様に行ってください。

3

- ⑭ パーツ番号の下部の穴からレースが飛び出ていないか確認してください。出ている場合は、再度レースを引っ張り直します。




- ⑮ ダイヤルをバイオネットに「カチッ」という音が鳴るまではめこみ完了です。動作確認は、使用方法(2ページ)に従って行ってください。



○ ひもで応急処置を行う方法

予備のレースが無い場合は、お持ちの靴ひもなどをエマージェンシーループとガイドに通すことで応急処置を行うことができます。



■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- レースの動きが悪いときはプラスチック製ガイドにシリコンスプレー(別売)を塗布してください。

■ 保管方法

- 風通しがよく、湿度が高くない場所で、直射日光を避けて保管してください。
- ※本製品の経年劣化を早める恐れがあります。以下のような場所には保管しないでください。
 - ・購入時の靴箱や収納袋
 - ・直射日光のあたる庭の物置
 - ・車のトランクなど高温になる場所

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理をさせていただきます。

■ 仕様

品番	1129632/1129633/1129634
品名	アルパインクルーザー® 800 BOA® Men's / アルパインクルーザー® 800 BOA® Women's / アルパインクルーザー® 800 BOA® ワイド Men's
付属品	ツール・本説明書

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

株式会社 モンベル 本社 〒550-0013 大阪市西区新町2-2-2 モンベルホームページ <https://www.montbell.jp/>
商品についてのお問い合わせはカスタマー・サービスまで Tel. 06-6531-3544 フリーコール: 0088-22-0031

4

mont-bell

User's Manual

Alpine Cruiser 800 BOA® Fit System

Alpine Cruiser 800 (BOA® Fit System)



Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

■ Features

These all-weather trekking boots are perfect for long distance trekking during summer. By using the BOA® Fit System, it is extremely easy and fast to adjust the fit and to take off the boots. By placing two dials on the instep and ankle, it is possible to achieve a very precise fit.

■ Components *Illustration of right shoe.



■ Safety Warnings!

Please read carefully.

WARNING! Under certain conditions, use of this product can result in injury, death, or property damage.

- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair function.
- Please follow recommended care and storage instructions. Improper care and storage can lead to a decrease in performance.
- In extremely rare cases, damaged laces can snap, creating sharp ends. When handling snapped laces be careful of cutting yourself.
- Prior to use, check the BOA® Fit System's condition and stop using immediately if you notice any damage or irregularities.

- When replacing laces, please refer to this user's manual. If replaced incorrectly, the laces may become damaged which can possibly lead to falling or tripping while wearing.
- If the lace becomes stuck inside the dial and the dial won't turn, replace the lace.
*Attempting to force the dial to turn can damage the BOA® Fit System.

CAUTION! Under certain conditions, use of this product can result in injury or property damage.

- Only use the specialized tool for taking apart the BOA® Fit System.
- Prior to use, check laces for damage.
- When wearing these boots, we recommend bringing the included tool, a spare set of laces and this manual.

■ Prior to use, inspect this product for;


Check the product's condition before each use and stop using immediately if you notice any irregularities.

☐ Damage on the dials


☐ Damage on the lace

■ Directions *Illustration of left shoe.

○ Loosening laces




Pull the dial forward until it clicks.




Pull the tongue forward to loosen the upper laces and pull the pull-tab to loosen the lower laces.

○ Tightening laces



Push the bottom dial until it clicks and turn clockwise to tighten.




Push the top dial until it clicks and turn clockwise to tighten.

○ Replacing laces

This product uses the BOA® Fit System. Although using an extremely strong stainless steel wire, the wire is subject to wear and tear, and may snap depending on the amount of use. Prior to use, check the lace for damage. If the lace is damaged or has snapped, please follow the instructions below on how to replace the lace. If you do not have a spare lace, in emergency situations it is possible to lace the shoes through the guides with whatever cordage you may have on hand.

Replacement recommended if:



- For replacing the lace by yourself, please follow the instructions below and purchase a Repair Lace.
- Montbell Stores and Montbell Customer Service can also replace laces (However, there is a fee for replacements done by Customer Service)

*Use only the tool for taking apart the BOA® Fit System

*Snapped laces are extremely sharp. When handling snapped laces be careful of cutting yourself.

*When wearing these boots, we recommend bringing the included tool, a spare set of laces or shoe laces, and this manual.


Please refer to the chart for correct lace length. Please purchase "#1129384 BOA® Fit System Repair Lace 0.81mm"

(cm)			
Shoe Size	22.0~24.5	25.0~27.5	28.0~29.0
Lace Length (Top Dial)	40	45	50
Lace Length (Bottom Dial)	75	80	85

⚠ This product requires a set of two laces for each shoe.



⚠ When replacing laces, work on one shoe at a time, using the other shoe as a reference.

- ① Insert the included tool and pry up to pop off the dial. ② Detach the pawl. ③ Remove the spool.



- ④ Remove the lace from the spool and shoe. Then, reinstall the pawl in the reverse order.

- ⑤ Push down on the top of the dial until it clicks, locking in place. ⑥ Turn the dial until the arrows on the dial and the spool align.






- ⑦ Thread the new lace through the guides.
*When threading, avoid bending the lace.
*If you have any difficulty, twist the lace as you thread it into the guide.
*If the shoe has a pull-tab, do not forget to pass the lace through it.

- ⑧ Thread the laces into the dial towards the opposite exit hole.

- ⑨ Take one of the laces and make a loop.




- ⑩ Pull the end of the lace through the loop.



- ⑪ Pull the end of the lace tightly to make a knot.


- ⑫ Leave between 4-7mm of lace on the end of the knot.

- ⑬ Pull the lace so the knot enters the dial.
*Check to make sure the knot is inside the dial.




7

- ⑭ Check the hole near the dial's part number and if the ends of the knot are sticking out of the hole, pull the lace so the lace is fully enclosed within the dial.




- ⑮ Push the dial into the bayonet until it clicks into place. Check that it's working correctly by following the instructions on page 6.



○ Using normal laces in an emergency

When replacement laces are not on hand, normal laces or cordage can be looped through the emergency loop and guides for temporary measures.



■ Care Improper care and storage of your boots can shorten their lifespan. Follow the recommendations below to extend the lifespan of your boots.

- If laces are not moving through the plastic guides correctly, lubricate the laces with silicone spray (sold separately).

■ Storage

- Store in a well-ventilated, cool, dry place. The following storage methods can cause these shoes to deteriorate quickly.
- The original box or bag at the time of purchase.
 - Any area that receives exposure from direct sunlight.
 - A car trunk or other area subject to high temperatures.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specifications

Style# : 1129632/1129633/1129634
Name : Alpine Cruiser 800 BOA Men's/Alpine Cruiser 800 BOA Women's/Alpine Cruiser 800 BOA Men's - Wide
Included : Tool and User's Manual

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

<https://www.montbell.com/>

8

44-4621-2112