ヌプリパック

取扱説明書

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明 書」といいます)は本製品の正しい取扱方法を説明しています。ご使用の前に本説明書をよ くお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスま でお問い合わせください。本説明書は大切に保管してください。

■ 特長

ウイッシュボーン システムを搭載した、素早く荷室にアクセスできるジッパー式の中型パックで す。1気室または2気室と切り替えて使用できるなど、多彩な機能を搭載。トレッキングや1泊2 日の小屋泊まり登山など、幅広い用途で使用していただけます。

■ 各部の名称/機能説明



- ●トップ部が大きく開くジッパーオープン式で、荷室へ のスピーディーなアクセスが可能。
- ②トップリッドの内側に小物を収納できるポケットを配置。
- ❸後頭部があたりにくいトップリッドデザイン。
- ❹手袋をしたままでも操作しやすいピッケルストラップ。
- ⑤荷物が少ないときに容量を調節したり、レインウエア 等を挟んでおけるバンジーコード。



- ⑥トップリッドを開閉せずに荷室にアクセスでき るジッパー。内部の仕切りを閉めることで2つ の荷室に分けることができ、荷物の整理に便
- ドリリースバックル (上部) を使用したベルト。 ❸小物の収納に便利なストレッチ素材を使用し たポケット (左右サイド)。
- ∮体格に応じて調節可能なチェストサポート。

ハイドレーションシステム

ハイドレーションシステムとは、行動中に効率よく水分補給できるシステムです。

別売のハイドレーションパックを装着することが出来ます。





ハイドレーションパックは本体 背面内側の L部のループにつ るして装着します。チューブは 涌し穴からパック背面に出して 使用します。パック背面の左右 どちらにも出すことができます。



ニューブをショルダーハー ネスのループ(①) に通し 飲み口の位置を調節しま す。チェストサポートに付 ている固定用フック 2) も併用します。

快適に背負うために パックがジャストフィットしている

状態とは、バックパネルとショル ダーハーネスが体に隙間無く接し ている状態のことをいいます。ご 使用にあたっては、ご自身の背面 長に合わせて、適切なフィッティン グを行ってください。



背面長とは

第7脊髓骨

(首を下に曲げた時にいちばん突起する骨) 背面長 (第7脊髄骨と、腰骨の最上部との長さ) 腰骨の最上部

腰骨回り

(左右の腰骨の最上部を通る身体周りの長さ)

11 ヒップベルトの位置を決める。

あらかじめ、各バックルに通したテープ類は適度に緩めておきます。また、体のラインを明確にする ため、できるだけ薄着での作業をおすすめします。

- ●使用時に近い状態を再現するため、10kg程度の荷 物をパックに入れます。
- ②パックを背負い、腰骨 の左右の出っ張りをラン バーパッドの中央部で包 み込むようにしてヒップベ ルトを固定します。



⋒ショルダーストラッ プを引いて、肩から脇 にかけてショルダー ハーネスが密着する ようにします。



-●からやり直し

ます。

2 3Dフィット・ステー (内蔵フレーム) を調節する。

●パックを背負い、ヒップベルトとショル ②すき間があるようなら、3Dフィット・ステー ③3Dフィット・ だくとスムーズに進めることができます。)

ダーストラップを締めた状態で、背中と をパックから取り出し、脚などを使って曲げ ステーをパックに パックの間に隙間がないか、鏡に映し 具合を調節します。一度に大きく曲げるの 戻し、手順 ■ て確認します。(他の方に手伝っていた ではなく、少しずつ曲げるのがコツです。



3 スタビライザーを調節する。

スタビライザーは、パックの揺れを抑え、体に引き寄せる機能をもちます。

●ショルダースタビライザーを引きます。このと き、🖹のバックルが肩の一番高い所より少し前 になるように調節してください。



の
トップスタドライザーを引いて、パックを引き 寄せ、チェストサポートを鎖骨から約5cmぐらい 下で留めます。



mont-bell

■ お手入れ方法 間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。 使用後や保管時は以下の点を参考にしてください。

- う背面の汗による汚れや泥の汚れは水で軽く洗い流した後に中性洗剤を含ませたスポンジ でブラッシングをし、洗剤を洗い流してから陰干ししてください。
- ○長期の使用により、撥水性能 (水を弾く力) が低下した場合は別売のS.R.スプレー等の 撥水スプレーをご使用ください。
- ○ドライクリーニングや洗濯機による洗濯はしないでください。生地を傷める恐れがあります。

■ 保管方法

○風诵しの良い場所に保管してください。

○ガソリンやシンナーと一緒に保管しないでください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がご ざいましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。 製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換 等の要否につきましては、弊社の裁量にて判断させていただきます。なお、以下のような原 因での破損、不良につきましては保証いたしませんのでご了承ください。

- ○本製品の誤った使用方法によるもの
- ○間違ったお手入れ、保管方法、経年変化による素材劣化
- ○刮、暴な取り扱いによるもの
- ○その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていた

■ 仕様

ヌプリパック 35 【重量】1.22kg 【容量】35L

#1223347 女性用モデル

ヌプリパック 35 Women's [重量]1.16kg [容量]35L

容量や機能、デザインはそのままに、背面長、ヒップベルト、ショルダーハーネスを女性の体に合わ せて設定しています。身長145~165cmくらいまでの方に最適なモデルです。

素 【本 体】 330 デニール・ナイロン・リップストップ [ウレタン・コーティング] 210デニール・ナイロン・ダブルリップストップ 「ウレタン・コーティング] 【底 部】1000デニール・バリスティック®ナイロン [ウレタン・コーティング]

ZERO-POINTの商品はすべてmont-bellによって制作されています。

※本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペック には誤差が生じる場合があります。

株式会社 モンベル 本社 〒550-0013 大阪市西区新町 2-2-2

商品についてのお問い合わせはカスタマー・サービスまで Tel. 06-6531-3544 フリーコール: @ 0088-22-0031 モンベルホームページ http://www.montbell.jp

44-2355-1611

Nupuri Pack

User's Manual

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product. If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future

Description

This middle sized backpack features a zippered top lid for easy access to the pack contents. In addition, an internal partition can be used to divide the main compartment into two compartments for organizing your gear. Great for trekking or overnight trips, the Nupuri Pack is an excellent multipurpose backpack.

Features



Hydration Compatible

Hydration bladders are sold separately. *For compatibility and size information, please see website for details

- Dippered top lid for easy access to pack contents.
- A discrete internal zippered security pocket for storing small items. @Tranezoid shaped top lid delivers more head.
- clearance for better vision and comfort.

Hose Port

6Bungee cord for addressing varying internal pack volume and as a space for stowing items for easy access, such as a rain jacket or windbreaker.

This pack is compatible with hydration bladders.

Hang the hydration bladder

rom the loop on the inside

of the back and slide it into

he pocket. Pull the hose

hrough the Hose Port to

n vour preference.

e left or right, depending

Internal partition for dividing the main

organizing your gear.

@Stretch mesh side nockets

compartment into two compartments for

Quick release compression straps allow you

attaching skis or stowing trekking poles.

OSternum strap can be adjusted vertically to

Pass the hose through

the loop on the shoulder

arness and adjust the

osition of the mouth

also be attached to the

piece. The hose can

ternum strap.

customize the shoulder harness

to address varying internal pack volume,

shoulder harnesses are in complete contact with the body. Refer to the following

Backpacks have a good fit when the back panel and instructions to adjust fit.

Seventh cervical vertebra (C7)

Torso length Measurement between C7 and the top of hip bones

Iliac crest Measurement around the top of hip bones.

1 Fitting

Before starting, unbuckle and loosen all straps. For a more precise fit, we recommend wearing light clothing to clearly define the shape of your back, shoulder and hips.

Maximizing Comfort

To simulate conditions during actual use, load about 10kg of weight into the backpack

Shoulder the product and fasten the hipbelt, taking care not to put pressure on your abdomen and making sure the center of the hipbelt wraps around your hipbone.



@Pull the shoulder straps so that they tighten around your shoulders and armpits.



2 Adjusting the 3D Fit Aluminum Frame

1 While wearing the backpack with hipbelt and shoulder straps adjusted, check your reflection in a mirror to confirm if there are any gaps between the backpack, your shoulders and back.



(Another person can make this step proceed more auickly).

2 If there are gaps, remove the 3D Fit Aluminum Frame from the backpack and use your thigh to make adjustments to the frame, bending it slightly. Make minor, gradual adjustments to the frame and avoid



After replacing Aluminum Frame, start over from

step 11-0.

3 Adjusting the stabilizers

Pull the load lifters to draw the backpack's

center of gravity in closer to your body. Pull the load lifters so that the buckle (A) is positioned just in front of the highest point of your shoulders.



Stabilizers will keep the backpack closer to the body and prevent the backpack from shifting. 2 Pull the hipbelt stabilizers to prevent the backpack from shifting left and right and fasten the sternum strap and adjust its position about 5cm below your collarbone to prevent the shoulder harnesses from shifting position.



mont-bell

Improper care and storage of your backpack can shorten its lifespan.
Follow the recommendations below to extend the lifespan of your backpack.

- ○To clean stains and soiling, lightly rinse off and use a mild soap with a sponge to brush away any remaining residue. Rinse off and hang to dry in the shade.
- OWater repellency will decrease over time. To restore water repellency, first clean any residues from the fabric surface and then apply a water repellant spray (sold separately).
- ODo not dry clean or wash in a washing machine. These methods may damage the backpack's

■ Storage

- Store in a well ventilated, cool, dry place.
- ODo not store together with corrosive materials.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at our discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specifications

Nupuri Pack 35 [Weight] 1.22kg [Capacity] 35L

Nupuri Pack 35 Women's [Weight] 1.16kg [Capacity] 35L

Without changing design or functionality, the hipbelt, shoulder harnesses, and back length have been adjusted to better fit the female form. This model is ideal for heights between 145cm and 165cm.

Main: 330-denier urethane coated rip-stop nylon 210-denier urethane coated rip-stop nylon om: 1000-denier urethane coated Ballistic nylon

ZERO-POINT products are made by mont-bell

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN www.montbell.com

44-2355-1611